



BBQ BOARDS™ STORAGE & MAINTENANCE INSTRUCTIONS

- **DO NOT** LEAVE BBQ BOARDS™ ON THE GRILL DURING COOKS.
- **DO NOT** LEAVE BBQ BOARDS™ IN DIRECT SUNLIGHT FOR PROLONGED PERIODS OF TIME.
- **DO NOT** STORE YOUR BBQ BOARDS™ OUTDOORS EVEN UNDER THE GRILL COVER.
- **DO NOT** LEAVE PELLET BIN BBQ BOARDS™ ON LID WITH LID OPEN.
- **REMOVE** BBQ BOARD™ FROM PELLET BIN LID PRIOR TO OPENING.
- **REMOVE** ALL BBQ BOARDS™ FROM GRILL WHEN NOT IN USE.
- **STORE** BBQ BOARDS™ INDOORS, ON A FLAT SURFACE, AWAY FROM DIRECT SUNLIGHT OR DRAMATIC TEMPERATURE CHANGES.
- **APPLY GENEROUS COAT** OF BBQ BOARD BALM™ (WAX) PRIOR TO FIRST USE TO PROVIDE WATER REPELLENT BARRIER & HELP PREVENT STAINING.
- **SEASON** YOUR BBQ BOARDS™ REGULARLY WITH BBQ BOARD BALM™ OIL & WAX TO PROLONG THEIR LIFE.
- **HAND WASH ONLY** WITH BBQ BOARD BALM™ SOAP OR A MILD SOAP & NEVER USE "GREASE CUTTING" DISH SOAP.
- **READ BACK PAGE** OF DOCUMENT INCLUDED WITH EACH BBQ BOARD™ FOR FULL USE & CARE INSTRUCTIONS.
- **REACH OUT** TO US IF YOU EVER HAVE ANY QUESTIONS OR ARE UNSURE OF SOMETHING. **BBQBOARDS@YAHOO.COM**