


**1**

18" / 45.72 cm




**2**

---

---

**3**



# 4


# CHESS/CHECKER BOARD

Print at 100%,  
Eight 8-1/2 x 11 Pages  
Line Up End to End in this Order  
for Pattern

1	2	3	4
5	6	7	8



May have white areas between  
pages just continue line work  
with pencil or pen,  
do not overlap



**5**


---

---

---

18" / 45.72 cm


**6**



SQUARES

2" X 2"

5.08 cm x 5.08 cm



CUT 64

32 OF EACH COLOR

**8**