


HIP POUCH PATTERN 2

Print at 100%,
Two 8-1/2 x 11 Pages
Line Up End to End in this Order
for Pattern



May have white areas between pages just
continue line work with pencil or pen,
do not overlap


8-1/2" / 21.59 cm

7/8" / 2.22 cm

6" #5 ZIPPER

6-1/2" / 16.51 cm

3/4" /
1.90 cm



9" / 22.86 cm

CUT 1
FLESH SIDE UP

25 MM

5-1/4" / 13.33 cm

