Eastham Outdoor Wall

CO1281, CO1291, CO1301, CO1311, CO1321 1.0

GENERATION LIGHTING OUTDOOR

GENERAL PRODUCT INFORMATION:

These fixtures are intended to be installed utilizing NEC compliant junction boxes.

This product is safety listed for wet locations.

Incandescent version may be dimmed with a standard incandescent dimmer. LED version may be dimmed with a LED dimmer. Consult lamp manufacturer for additional information.


This instruction shows a typical installation.

CAUTION - RISK OF FIRE

This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.


Use minimum 90°c supply conductors.

SAVE THESE INSTRUCTIONS!



GENERATION LIGHTING 7400 Linder Ave., Skokie, IL 60077 T 847.410.4400 | F 847.410.4500 www.generationlighting.com

Install the Fixture



Temporarily install the mounting plate to the junction box

2 Mark the anchor locations through the holes on the mounting plage. Remove the mounting plate.

3 Drill appropriate sized holes and install the anchors at the marked locations.

4 Secure the mounting plate to the junction box and screw the anchor screws through the anchors.

5 Connect the fixture to a suitable ground in accordance to local electrical codes.

6 Connect the white fixture wire (square and/or rigid) to the neutral power line wire with a wire nut.

Connect the black fixture wire (round and/or smooth) to the hot power line wire with a wire nut.

8 Neatly place all the wires into the junction box, place the canopy onto the mounting plate, and secure it in place using the fixture screws.

9 Place the shade onto the shade base, then place the cover onto the shade and cover support and secure it in place with the cover screws.

Screw the lamp into the socket. Refer to the label on the lamp socket for Max Wattage Information.

For wet locations, caulk around the base of the fixture with waterproof construction sealant.