
## **ASSEMBLY INSTRUCTIONS**









## **Cawdor Stanchion Wall Light**

Item # CHD 2300

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.

WARNING\*\*\*SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT. DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

NOTE: CAREFULLY UNPACK EACH PIECE IN TOP LAYER OF PACKING PRIOR TO REMOVING. RETAIN ALL PACKING MATERIAL UNTIL INSPECTION AND INSTALLATION ARE FINAL.

- 1. Carefully remove all parts from the box.
- 2. Remove the mounting plate (B) from the backplate (D) by loosening the finial (E).
- 3. Affix mounting plate (B) onto the outlet box and secure with mounting screws (C).
- 4. Connect the hot wire (BLACK) from the fixture to the hot wire from the outlet box (usually BLACK). Fasten them together with a plastic wire connector (A) provided and wrap the connection with electrical tape.
- 5. Connect the neutral wire (WHITE) from the fixture to the wire from the outlet box (usually WHITE).
  - DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.
- 6. Connect ground wire from the fixture (bare copper) to ground wire from the outlet box (usually green or copper in color).
- IT IS IMPERATIVE THAT THIS FIXTURE BE GROUNDED.
- 7. Attach the backplate (D) onto the mounting plate (B) and secure with finial (E).
- 8. Drill one hole one the wall and knock the anchor (F) into the wall hole.
- 9. Attach the thread washer (G) to the wall and secure with screw (H), then thread the plate (I) to it.
- 10. Attach the harp (L) to the saddle (M).
- 11. Place the shade (K) to the harp (L) and secure with the finial (J).
- 12. Insert bulb (not included) into the socket.
- 13. Installation is complete, turn on power at fuse or circuit breaker.



<sup>\*\*\*</sup>Clean with a dry, soft cloth only. Use no harsh abrasives or chemical agents.