
ASSEMBLY INSTRUCTIONS









Rosedale Grand Large Hanging Lantern

Item # RC 5049

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.

WARNING***SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT. DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.


NOTE: CAREFULLY UNPACK EACH PIECE IN TOP LAYER OF PACKING PRIOR TO REMOVING. RETAIN ALL PACKING MATERIAL UNTIL INSPECTION AND INSTALLATION ARE FINAL.

- 1. Carefully remove all parts from the box.
- 2. Thread the finial (J) to the nipple (K), then thread the finial (O) to the bottom of the fixture body (M).
- 3. Hang the hook (N) on the hanging loop (L).
- 4. Hang the rod (I) one end to the hook on the hub (H), one end to the hook on the fixture body (M).
- 5. Provide a 1/4" IPS pipe with one end securely mounted to a beam or a structural member.

 The other end should protrude through the center of the outlet box as shown.
- 6. Install the threaded nipple (B) into the support pipe and adjust overall length to allow the canopy ring to hold the canopy flush to the ceiling.
- 7. With the fixture desired height, shorten the chain (F) as needed using a pair of chain pliers.
- Open one chain quick link, then attach the chain quick link to the hanging loop (G).Secure the chain quick link.
- 9. Let collar ring (E) and canopy (D) go through the chain (F).
- Open another chain quick link, then attach the chain quick link to the ceiling loop (C).
 Secure the chain quick link.
- 11. Weave the power supply cord and the ground wire through the chain (F).
- Feed the fixture wire and ground wire through the ceiling loop (C) and pull until taut.
 Measure the wires then cut. Be certain to leave enough length to connect inside of the ceiling junction box.
- 13. Strip the insulation back on the two power supply wires about 5/8".
- 14. Twist the power supply and ground wire together and push through the center hole of the ceiling loop (C).



ASSEMBLY INSTRUCTIONS









Rosedale Grand Large Hanging Lantern

Item # RC 5049

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.

WARNING***SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT. DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.


NOTE: CAREFULLY UNPACK EACH PIECE IN TOP LAYER OF PACKING PRIOR TO REMOVING. RETAIN ALL PACKING MATERIAL UNTIL INSPECTION AND INSTALLATION ARE FINAL.

- 15. Connect the fixture ground (bare) wire with the ground wire from the outlet box using wire nut (A). If your house does not have ground wire, then attach this wire to the green grounding screw inside of the outlet box.
 - IT IS IMPERATIVE THAT THIS FIXTURE BE GROUNDED
- 16. Connect the fixture Neutral wire (ribbed) with the neutral wire (usually white) from the outlet box using wire nut (A).
- 17. Connect the fixture Hot (smooth, marked with words) wire with the hot wire (usually black) from the outlet box using wire nut (A).
 - DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.
- 18. Tuck these wire connections neatly into the outlet box to secure.
- 19. Put canopy (D) flush to the ceiling, and secure with collar ring (E).
- 20. Rotate the door knob (V) 180 degrees to open the door.
- 21. Attach the glass panels (P) on the side of the frame and secure by bending the metal tabs.
- 22. Attach the glass panel (Q) on the door of and secure by bending the metal tabs.
- 23. Insert bulbs (not included) into the sockets, then close the door.
- 24. Installation is complete, turn on power at fuse or circuit breaker.



^{***}Clean with a dry, soft cloth only. Use no harsh abrasives or chemical agents.

ASSEMBLY INSTRUCTIONS









Rosedale Grand Large Hanging Lantern

Item # RC 5049

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.

WARNING***SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT. DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

NOTE: CAREFULLY UNPACK EACH PIECE IN TOP LAYER OF PACKING PRIOR TO REMOVING. RETAIN ALL PACKING MATERIAL UNTIL INSPECTION AND INSTALLATION ARE FINAL.

When you do not need the chain, you can follow below assembly instructions:

- 1. Unthread the hook (C2), keep the ceiling loop (C1) stay with the threaded nipple (B).
- 2. Unthread the hanging loop (G), then thread the connector (R) to the hub (H).
- 3. Put canopy (D) flush to the ceiling, and secure with collar ring (E).
- 4. Thread the connector (R) with hub (H) to the ceiling loop (C1).
- 5. Loosen the collar ring (E) and slip down canopy (D) carefully.
- 6. Hang the rods (I) to the hub (H), then loosen the finial (U) and remove the hub cover (T) from the hub (H).
- 7. Feed the wire pass through the hole on the hub (H), then the hickey (S), then the ceiling loop (C1) and pull until taut.
- 8. Attach the hub cover (T) to the hub (H) and secure with finial (U).
- 9. Follow the step 15-24 for wire connection and glass assembly.