



1999-2002 Yamaha R6

Engine	Axle	1st	2nd	3rd
11	45	22.75	15.56	12.43
11	46	23.26	15.91	12.71
11	47	23.76	16.26	12.98
11	48	24.27	16.60	13.26
11	49	24.77	16.95	13.54
11	50	25.28	17.29	13.81
11	51	25.78	17.64	14.09
11	52	26.29	17.98	14.36

Engine	Axle	1st	2nd	3rd
14	45	17.87	12.23	9.77
14	46	18.27	12.50	9.98
14	47	18.67	12.77	10.20
14	48	19.07	13.04	10.42
14	49	19.46	13.32	10.63
14	50	19.86	13.59	10.85
14	51	20.26	13.86	11.07
14	52	20.66	14.13	11.29

Engine	Axle	1st	2nd	3rd
12	45	20.85	14.27	11.39
12	46	21.32	14.58	11.65
12	47	21.78	14.90	11.90
12	48	22.24	15.22	12.15
12	49	22.71	15.53	12.41
12	50	23.17	15.85	12.66
12	51	23.63	16.17	12.91
12	52	24.10	16.49	13.17

Engine	Axle	1st	2nd	3rd
15	45	16.68	11.41	9.12
15	46	17.05	11.67	9.32
15	47	17.42	11.92	9.52
15	48	17.80	12.17	9.72
15	49	18.17	12.43	9.93
15	50	18.54	12.68	10.13
15	51	18.91	12.94	10.33
15	52	19.28	13.19	10.53

Engine	Axle	1st	2nd	3rd
13	45	19.25	13.17	10.52
13	46	19.68	13.46	10.75
13	47	20.11	13.75	10.99
13	48	20.53	14.05	11.22
13	49	20.96	14.34	11.45
13	50	21.39	14.63	11.69
13	51	21.82	14.93	11.92
13	52	22.24	15.22	12.15

Engine	Axle	1st	2nd	3rd
16	45	15.64	10.70	8.55
16	46	15.99	10.94	8.74
16	47	16.34	11.18	8.93
16	48	16.68	11.41	9.12
16	49	17.03	11.65	9.31
16	50	17.38	11.89	9.50
16	51	17.73	12.13	9.69
16	52	18.07	12.36	9.88