

Quick Start Guide

Premium Essential Oil Diffuser



FOR A BETTER LIFE



ASAKUKI

あさのくき

ASAKUKI Be With You Anytime

ASAKUKI originated from Japan, we focus on designing and creating household items for a better life. The word "ASAKUKI" comes from the Japanese pronunciation (朝の空気-あさのくうき "air in the morning") whose products relate to healthy family life.

Utilizing our experience and success in the industry, ASAKUKI has created a customized and unique project management team, designed to fulfill our customers' requirements with the highest quality household items based on innovation, excellence, and comfort, using the latest technology.

Together with a 100% satisfaction guarantee, we want to let you know that if you need any questions or concerns, please feel free to contact our customer support team by simply emailing us via Amazon message.

Need Help?

Our support team is ready to help you!

Email: support@asakuki.com

Package Contents

This manual book applies to all same model diffusers in different colors



Marble



White Wood



Light Wood



Brown Wood



Pure White



Pink



Blue



Dark Blue



Dark Green



Black



Diffuser*1



User Manual*1



Remote Control*1



Power Adapter*1



USB Cable*1



Notice:

The power adapter is included in the water tank.

Using Your Essential Oil Diffuser



Connect
the power

Add

water and essential oil in the tank



Press the left "Light" button to adjust the LED light
Press the right "Mist" button to turn on/off the diffuser or set a timer
Use the remote to try more function

How to Use Remote Control



ON/OFF



Intermittent



Timing



Continuous



Big/small



Light

TECHNOLOGY FOR LIFE
MADE IN CHINA

ON/OFF

First press: Turn on the mist and set at continuous misting mode.

Second press: Turn off the mist and light.

Intermittent

When the diffuser is turned on, press to set to intermittent mist mode.

It will mist for 10 seconds and stop for 10 seconds and cycle.

Continuous

When the diffuser is turned on, press to set to continuous mist mode.

Timing

When the diffuser is turned on:

First press: Set at 2-hour mist mode.

Second press: Set at 4-hour mist mode.

Third press: Set at continuous mist.

Big/Small

(Big/Small mist mode can only be set by remote control)

Press to adjust the mist density, one beep for strong mist,

two beeps for weak mist.

Light

One press: Turn on the light and each color cycles.

Next press: Fix each color at dim or bright mode and turn off the light.

Manual Control Guide



LIGHT Button

1. After the USB cable is connected, press the "LIGHT" button once to turn on the light. The LED light color will cycle from dim to bright gradually.
2. Continue pressing will fix the color at a bright or dim status.
3. Long press for 3 seconds to turn off the light.



MIST Button

1. Short press the "MIST" button once to turn on the spray, and the spray time will be set to continuous on.
2. Continue to press to set spray time to intermittent/ 2H/ 4H and turn off.

Maintenance & Notice

Clean & Maintenance

Please clean the diffuser per week as follows:

- **Unplug the diffuser and pour out the remaining water from the "DRAIN SIDE".**
- Add 2-3 drops of vinegar to 100ml warm water(up to 70°C/ 158°F).
- Leave the diffuser for 5 minutes and gently shake and pour out the water.
- Wipe the diffuser with a dry soft cloth.
- If the diffuser will not be used for a long time, please keep it clean and dry.

Notice

- When filling the water, do not exceed the max line marked on the water tank.
- Please power off the diffuser before adding water.
- The device will beep twice and automatically shut off when water runs out.
- Please use pure natural essential oils.
- If the diffuser is leaking for any reason, please unplug the unit and pour out the remaining water. Shake the diffuser gently to drain water inside, then dry for more than 24 hours.



72h Clean the water tank every 3 days

- Be aware that high humidity levels may encourage the growth of biological organisms in the environment.
- Do not permit the area around the diffuser to become damp or wet. If dampness occurs, turn the mist density to a lower level. If the mist density cannot be turned to a lower level, it is recommended to use the oil diffuser intermittently. Do not allow absorbent materials, such as carpeting, curtains, drapes, or tablecloths, to become damp.
- Unplug the appliance during filling and cleaning.
- Never leave water in the reservoir when the appliance is not in use.
- Empty and clean the oil diffuser before storage. Clean the oil diffuser before the next use.



Warning: Micro-organisms that may be present in the water or in the environment where the appliance is used or stored, can grow in the water reservoir and be blown in the air causing very serious health risks when the water is not renewed and the tank is not cleaned properly every 3 days.

4 DIY Essential Oil Blends



Lavender

+



Orange

Good Night Sleep



Clove

+



Grapefruit

Goodbye Mold



Basil

+



Geranium

+



Orange

Brain Booster



Geranium

+



Lavender

+



Oregano

Anti Allergy

Troubleshooting

Problem	Cause	Troubleshooting Tips
No power	The power cord is loose or not connected	Check the power jack and the plug, make sure they are correctly connected
	The power strip is defective	Try a new power strip
	Internal damage	Contact Customer Service Team
	Water runs out	Check the water tank and add enough water
The diffuser lights up but no mist comes out	Water scales and essential oil particles clog the ultrasonic sheet	Wash the water tank with a warm mixture of 10% vinegar and 90% water. Then clean the round ultrasonic sheet inside the water tank with a dry cloth. It is recommended to add a mixture of vinegar and water to the water tank and let it rest for at least 10 minutes before cleaning.
	The air outlet is clogged	Clean the air outlet with a dry cloth
	Place the diffuser on carpet or a towel	Remove anything under the diffuser. Always place a diffuser on a flat table.

Troubleshooting

Problem	Cause	Troubleshooting Tips
The diffuser is leaking water	Overfill the water tank	Water should never exceed the max line on the water tank. Pour out 1/3 water and try again.
	High relative humidity and insufficient airflow in your room prevent the air from fully absorbing water particles. Then water puddles form on the countertop, which looks like the diffuser is leaking.	Measure the humidity and turn off the mist.
	The water tank or the base is already cracked	Contact Customer Service Team
Strange smell	Essential oil residue emits a stinky smell	Make sure to drain the water completely and clean the tank after each use.
	Other smell	Contact Customer Service Team
Red light keeps flashing	Water runs out	Check the water tank and add enough water
	The overheating protection is activated.	Turn off the diffuser and let it rest for at least 15 minutes before starting it again.
Barely smell a fragrance	People have different sensitivities to the scent of essential oils, and essential oils diffuse at different speeds.	It is recommended to add 4-6 drops of essential oil per 300ml of water. If the scent isn't as strong as you want, keep adding more essential oil drops until you are satisfied.

If your problem is not listed, please contact Customer Support. Email us at support@asakuki.com

Specifications

Tank Capacity	300ml
Timer	ON/INT/2H/4H
LED Colors	7 Bright, 7 Dim
Ultrasonic Frequency	2.4MHz
Product Dimensions	135*135*95mm
Product Weight	370g
Power	5W
Power Input/Output	5V/1A
Product Materials	PP/ABS
Package Content	Power Adapter, USB Cable, Remote Control, User Manual

Warranty Information

Product Name	Essential Oil Diffuser
Model	AD003
For your own reference, we strongly recommend that you record your order ID and date of purchase.	
Date of Purchase	
Order ID	



If you discover that your product is defective within the specified warranty period, please contact Customer Support via support@asakuki.com. DO NOT dispose of your product before contacting us.

Please register within 60 days of purchase to extend the 1-year product warranty to a total of 2-year product warranty. To make the customer support process quick and easy, register your product online at asakuki.com/pages/warranty.

Customer Support
Email: support@asakuki.com

*Please have your order invoice and order ID ready before contacting Customer Support

Brand: ASAKUKI
Product Name: Essential Oil Diffuser
Model Number: AD003
WEEE-Reg. -Nr: DE: DE 41980660 FR: FR031399 05UERI
Manufacture: Chongqing ChuangHong Dian Zi Shang Wu You Xian GongSi
Address: 1 zhuang 11-3, jin kai da dao 1228 hao, bei bu xin qu, Chongqing, 401120, China

UK REP

UK Responsible Person: JunBright Ltd
Address : 51 Chalton Street London, England, NW1 1HY
Email: yldyx112@outlook.com

EC REP

EU Responsible Person: C&E Connection E-Commerce (DE) GmbH
Address : Zum Linnegraben 20, 65933, Frankfurt am Main, Germany
Email: info@ce-connection.de



MADE IN CHINA



ASAKUKI-Direct



asakuki_official



ASAKUKI.com