




Step 1: Check the generator for gasoline. Add as needed.



Step 2: Turn fuel valve on by rotating valve counter clockwise.




Step 3: Switch the main breaker to OFF.




Step 4: Move the choke lever to the CLOSED position.




Step 5: Flip the switch up to the "START" Position. When the engine starts, allow the engine switch to return to the "RUN" position.




Step 6: Move the choke lever to the OPEN position.



Step 7: Once the generator is running, turn the main breaker to ON and plug devices in.



Step 8: Plug your devices in.



Note: To ensure the maximum life of your generator, be sure to check the oil before every use.

ASSEMBLING YOUR GENERATOR

Step 1: Remove the generator from the box and flip it over, so you can see the underside of the generator.



Step 2: Remove the shipping brace using the included wrenches. Braces can be discarded.



Step 3: Secure the support legs to the frame with the provided lock nuts.



Step 4: Insert wheel axle bolts through frame and secure with the provided nut and wrenches.



Step 5: Insert axle bracket bolts through frame and secure with the provided nut and wrenches.



Step 6: Place one of the large washers onto both sides of the axle behind the wheel.



Step 7: Place the wheels onto either side of the axle.



Step 8: Place the other large washers onto each side the axle in front of the wheel.



Step 9: Place a cotter pin through the hole in each end of the axle and bend it out to secure the wheels.



Step 10: Attach the handles to the brackets on the frame using the provided bolts and nuts.



Step 11: Flip the generator over and sit it on its wheels.



Step 12: Connect the battery terminal.



Step 13: Replace the battery terminal cover.



Step 14: Add oil to the generator.



Note: The following set of instructions are a list of simplified steps to operate your generator. These steps are covered in greater detail within the product manual along with safety warnings, guidelines for maintaining your generator, and details about your generator's warranty.

We strongly recommend after assembling your generator you read the entire product manual to ensure that you understand how to operate your generator properly and safely.