


**VeCOAX ULTRA+**  
**FIRMWARE UPDATE PROCEDURE**



**IMPORTANT**  
**DO NOT LOSE POWER DURING THIS OPERATION**  
**IF NECESSARY, USE A BATTERY BACKUP UNIT TO**  
**POWER THIS PROCESS**

1) Connect your windows computer to the minimod 2+ using a USB cable




2) Install the USB DRIVER on your windows pc






### 3) Run the B2UPDATE application





Search for the COM and confirm it is found and selected




From the FILE menu > LOAD FILE > browse the new firmware upgrade file

The UPGRADE FILE has extension **.STB**






4) Click **DOWNLOAD** to start the upgrade




5) Wait the upgrade to complete – you will see the following message






6) Unplug the power from the unit

7) Reconnect the power and check the new version is installed




8) After reboot, execute a FACTORY RESET so the new firmware will clear all the parameters.



9) Set again the final parameters you need ( standard / channel / name etc) following the ULTRA+ installation guide from this link

<https://shop.provideoinstruments.com/pages/tech-support-for-vecoax-ultra-plus-hdmi-sdi-qam-atsc-dvbt-isdbt-dvbc-digital-television-broadcast-hdtv-rf-encoders-modulators>

You can also click the back arrow button and RECAL A PRESET so the unit will set all for you at once



**10) Test the unit for proper operation.**