

CALIBRATION MODE SETTINGS FOR ED SERIES

1. Make sure the scale is off.
2. Under the scale is a calibration plate with two brass bolts covering the calibration switch. Remove the calibration plate.
3. Press and hold the switch while turning the scale on with the “**ON/OFF**” key. The display will show “**onE**” and then “**CAL 1**”.
4. The “**▲**” key advances through the cal settings whereas the “**▼/PRINT**” key goes down. The “**SET**” key enters the cal setting.
5. Press the “**▲**” key three times until the display shows “**CAL 4**”. Press the “**SET**” key to enter into the setting mode. The “**▲**” key will increase the flashing digit and the “**▼/PRINT**” decreases the flashing digit. The “**◀/MODE**” or “**▶/SAMPLE**” can be used to select which digit is flashing. After setting C41 press the “**SET**” key. After setting C43 press the “**SET**” key again and the display will go back to “**CAL 4**”.

C41	b4
C43	6F

7. Press the “**ZERO**” key, the scale will show the version, count up, and go to the weigh mode.