

# Kitchen scale calibration

## (3keys)

### PARAMETER SETTING

1. Press and hold **【TARE/ZERO】** key and turn on the scale, window shows a group of number (Offset Values).

2. Auto Power off : press **【UNIT】** key to enter auto power off setting ,it displays A---10.

Press **【TARE/ZERO】** key can select in turn: A---0,A---1,A---5,A---10

A---0: no auto power off                    A---1:1 minute auto power off

A---5:5 minutes auto power off        A---10:10 minutes auto power off

3. Backlight setting: Press **【UNIT】** key to enter backlight setting, it display b---1.

Press **【TARE/ZERO】** can select in turn: b---1,b---0.

b---1    backlight on            b---0    backlight off

4. Capacity Setting: press **【UNIT】** key to enter capacity setting, it displays C10lb

Press **【TARE/ZERO】** key to choose capacity C3lb,C6lb,C10lb,etc.

C3lb    Max 3lb    e=d=0.0005lb

C6lb    Max 3lb/6lb e=d=0.0005lb/0.001lb

C10lb    Max 5lb/10lb e=d=0.001lb/0.002lb

C12lb    Max 6lb/12lb e=d=0.001lb/0.002lb

5. Press **【OFF】** key to finish parameter setting.

### UNIT SETTING

In the normal weighing status ,Press **【UNIT】** key to select kg or g unit

### CALIBRATION SETTING:

1. Turn on the scale, in the normal weighing status

2. Press **【TARE/ZERO】** and **【UNIT】** keys about 5 seconds, it displays inner code.

3. Press **【TARE/ZERO】** one time, scale display CALL→[xxxx], xxxx is full capacity.

4. Put the weight on the scale according to scale display value. Scale automatic calibration, When the calibration is finished, the scale back to normal weighing.