

## PROGRAMMING FOR SC-SERIES

1. Make sure scale is **OFF**. Remove the platter and find the *CALIBRATION PORT* located on the front left side of the top cover.
2. The *CALIBRATION PORT* is covered by two brass *SEALING BOLTS* and a silver plate. Remove the two *SEALING BOLTS* and the silver plate. You will see a red *MICRO SWITCH*.
3. Slide the *MICRO SWITCH* to the right. Put the platter back on the scale.
4. Turn scale **ON** and the *WEIGHT* display should flash "CAL" three times and then go blank.
5. Press the 4 key.
6. Press the following keys: 0 key, the 0 key, and the STORE key.
7. Select the proper setting from the chart and then press the STORE key.

*If you select the kg option then the scale must be calibrated using kilogram weights and the scale will automatically weigh in kg when you turn it on. This is also true for the lb option.*

	POUNDS SETTINGS	KILO SETTINGS
<b>SC-05P</b>	80	00
<b>SC-10P</b>	81	01
<b>SC-25P</b>	82	02

8. Press the following keys: 0 key, the 0 key, and the STORE key.
9. Press the following keys: 0 key, the 0 key, and the STORE key.
10. Once the scale displays go blank, press the 0 key. The scale will count up from 0 to 9 and then go to ZERO.

If all options are **NOT** working properly, repeat steps 1 to 10.

**OR**

If all options are **OK**, turn scale **OFF**, remove the platter, slide the *MICRO SWITCH* to the left, replace *SEALING BOLT* and silver plate, and replace the platter.

11. You are done.