

## TVS Calibration Manual

1. Turn on the scale. Press and hold "TARE" key during self-check until display shows "F1 CAL".
2. Then press the calibration switch, which is located below the battery (shown in the picture below) with a sharp material.
3. Press "ZERO" to confirm and display will show kg.
  - a. If calibrating in kg, continue step 3
  - b. If calibrating in lb, press "TARE" key and "lb" will be shown on the display.

Remove the goods from the platform.

NOTE: "TARE" key can be used to switch between "lb" an "kg"

4. Press "ZERO" to confirm and display will show "unload"
5. Press "ZERO" again and select the max calibration weight value by pressing "TARE" to select the weight value. (20lb, 40lb, or 60lb).
6. Place the weight on the platform. When the stable indicator is on, press "ZERO" key to confirm and "PASS" message will be shown on display.
7. Scale will restart.
8. In case display shows any error message or incorrect measurement, repeat the calibration steps stated above again.

