



# single digital output

UST-M18#S-T#S Created: 12/07/2016

## M18 LEDs





## CONFIGURATION STATE




A, B ON, WHEN TARGET IS IN WINDOW.  
C ON, WHEN ECHO IS RECEIVED.



## OUTPUT STATE



HOLD PUSH BUTTON FOR 8 SECONDS TO SWITCH  
FROM NO TO NC CONFIGURATION  
A, B, C START BLINKING UNTIL RELEASE




## TEACH OPTIONS



## RECALL FACTORY PARAMETERS

### TEACH WITHOUT TARGET



A, B, C ON, BLINKING TOGETHER 5 TIMES