

33, 40, AND 50 FOOT RETRIEVAL TOOL

ENGAGING SLIDE HANDLE ▶

A



Remove retrieval tool from packaging.

Carefully and completely uncoil tool to relieve tension on the pull cable.

E



Move the slide handle to align with the ball anchor mount hole and place slide lock screw through.

Make sure to insert slide lock screw in the threaded through-hole on the side of the slide handle.

B



Unthread the slide lock screw from the slide handle with the provided screwdriver.

F



Re-thread the slide lock screw into the slide handle.

The tool is ready for use.

C



Remove the slide lock screw from the slide handle.

Set the slide lock screw to the side.

D



Locate the ball anchor mount hole that is exposed in the slot of the slide shaft.

COILING NOTES ▶

10 meter (33 ft), 12 meter (40 ft) and 15 meter (50 ft) retrieval tools will not function without following these QuickStart steps. The disengaged slide handles allow for compact coiling.

These tools will not function properly if they are coiled tightly.

DO NOT coil extended length retrieval tools with slide handle engaged.



WARNING! DO NOT BEND OR KINK RETRIEVAL TOOLS AT ANY LENGTHS.

303 STATE ROUTE 94 | COLUMBIA, NJ 07832 | WWW.INTERTEST.COM

OFFICE: 908.496.8008 | HOURS: M-F, 8AM TO 5PM EST | EMAIL: SERVICE@INTERTEST.COM