


## IMPORTANT

- Retrieval tools will not function without following these QuickStart steps. **Read all instructions before proceeding.**
- The tool will not function properly if it is coiled tightly
- To recoil tightly, the handle must be disengaged. **Follow these QuickStart steps in reverse to disengage the handle.**
- Scan QR Code for video instructions



**A** Open **spring lock** and **cable lock**. Insert retrieval tool through the entrance hole.



**D** Insert the spring and with the slide handle all the way back adjust the spring




**B** The cable end should go as far into the slide cable lock as it will go.



**E** Ensure the tool is completely closed or at needed opening size. Lock the **spring lock**.



**C** Close the **cable lock**.



**F** With the **slide lock** is down the slide is free to move. When the **slide lock** is up the slide handle is locked.

**WARNING: DO NOT BEND OR KINK THE RETRIEVAL TOOL AT ANY LENGTH**



303 Route 94 Columbia, NJ 07832  
+1 908 496-8008

www.intertest.com  
service@intertest.com