

Maintenance and Cleaning Instructions For Menu Cases

Metal Parts

Lacquered Bright Metal Parts

- Not recommended for use in coastal areas.
- In order to prolong the life of the protective lacquer regular cleaning with water containing a mild liquid detergent (i.e. washing up liquid) is beneficial. A Soft cloth soaked in the water detergent mix should be used rinsing the cloth regularly to remove any particles that may scratch/damage the lacquer and then the product dried with a soft cloth lightly buffing to remove any water marks. Under no circumstances should abrasive cleaners be used.

Non Lacquered Bright Metal Parts

- Should be polished regularly with a soft cloth and a proprietary metal cleaner (ie brasso) used where necessary to restore the polished finish. Abrasive cleaners should not be used.

Painted Metal Parts

- Care should be used to avoid damaging the paint therefore it is recommended that the procedure for Polished and Lacquered parts is followed.

Glazing

Toughened Glass

- May be cleaned with a suitable glass cleaner and cleaning cloth.

Plastics

- Care should be taken as they are less resistant to scratching. Warm water with a small amount of liquid detergent and a soft cloth are recommended.

Hardware

- Locks and hinges require minimal maintenance. A small amount of machine oil applied occasionally will ensure ease of operation.

Felt Pinboards

- To prevent premature aging avoid positioning in direct sunlight. Felt may be cleaned with a soft brush or light strokes with a lint free cloth.