



Menu Cover Fixings Explained

TYPE	IMAGE	DESCRIPTION	HOLDS...
Tag Fixings		Tag fixings are a similar design to treasury tags, and run down the inside spine of the menu cover, secured at the top and the bottom of the menu cover through eyelets.	Tag fixings hold double plastic pockets in place. Each double plastic pocket shows 4 viewing sides.
Corner Retainers		Corner retainers are 4 fixings located at each corner on the front and back inside covers. Your menus are held in place by being tucked under each corner fixing. These fixings show 2 viewing sides.	Your menus slot directly into the menu cover fixings without the need for plastic pockets.
Ring Binder		A strong ring binder mechanism is fitted to the inside of the menu cover. 4 Rings are used for an A4 sized folder, and 2 are used for an A5 size.	The ring binder holds single pockets in place. Each single pocket shows 2 viewing sides.
Elasticated Cord		An elasticated cord is sewn into the top and bottom of the inside spine. Your menu then simply slides underneath to be held in by the elastic cord.	The elastic cord is designed to hold your menu cover without the need for plastic pockets.
External Screw Fixings		Brass or Silver Screws are used to screw through the menu cover, which hold your internal pockets in place. These can be easily unscrewed by hand to add/remove pockets as required.	Screw Fixings hold single pockets. Each single pocket shows 2 viewing sides.
Internal Screw Fixings		Screw fixings secure your pockets in place along strips of material on the inside spine of the menu cover. There are additional flaps of material to prevent the screws from marking the inside of the cover.	Screw Fixings hold single pockets. Each single pocket shows 2 viewing sides.

