



# Patio Chaise Lounge Chair With Table Assembly Manual




- Prior to assembly, please confirm all of the parts listed included.
- All bolts should be tightened before use. Maybe, you need allen wrench for assembly.
- Missing Part?Damaged?Contact us via email at service@domioutdoorliving.com




(K)**Assemble four** (B) legs Part C,Part **D,Part F and** Part E to the (D)seat Part B with srews Part K. **Assemble Part A** to the seat Part B, then assemble **Armrest Part I** and Part J to the seat Part B. Then use screws **Part L and Part** P to lock the legs. Tighten all srews before using.

Assemble backrest Part G and adjustable gear Part H together using screws Part K and Part N.




Assemble backrest and adjustable gear to the seat Part B with screws Part R.






## **Table Assembly Manual**

#### Part list



Step 1: Insert Part B(four legs) to Part A(table top).



Step 2: Set the chair straight.





## RESORT COMFORT IN YONR OWN BACKYARD

#### Thanks for your purchase.

At domi outdoor living, we believe in our products.

That's why we provide a 12-month warranty and friendly, easy-to-reach after-sales service. So if you have any questions about our product and assembly,please feel free to contact us. We will be here for you.

### Support:





email: service@domioutdoorliving.com

Please tell us your order ID when contact.

Attach photos of damaged part for instant reply.