

5.4'×3.7'TOOL STORAGE SHED MODEL#: LGCF1602

ASSEMBLY MANUAL



Missing part?Damaged?Contact us via emali at service@domioutdoorliving.com

© copyright 2019-2023 Domi Outdoor Living LLC. All Rights Reserved.

Pre-assembly



1.Two or more people are required for assembly.



2.You will need one or more stepladders.



3. Wearing protective gloves is recommended.



4.You may need a safety hat.



5.Please use a Phillips screw driver.



6.For ease of construction, you may need a drill.



7.You may need a safety goggle.



8.Do not fully tighten screws prior to complete assembly.

Warning & Attention

-Try to assemble this product on the flat ground, otherwise it is difficult to carry out;

-It would be much easier to assemble the product with three or more people;

-After assembly, please check whether all screws are tightened, to prevent parts from falling apart.

A Use bolts to secure the frame to the ground to against the strong wind.









Appendix





3. Place part#J2 on the bottom frame(A3), using 2 screws 1# and gaskets to fix.

Repeat the above procedures to assemble the another side.

4. Fix the part #C3 to the part #C1(C2) with 4 screws 3#, 8 gaskets and 4 nuts, (the gaskets and nuts are on the back side as shown in ③④).





3. Install 2 part #H with 4 screws 9# and gaskets, then put on the plastic caps as shown in 3(4).











- 35 screws 1# and gaskets as shown in ①②.
- 2. Fix the part #C4 to the upper end of part #C1(C2) with 4 screws 3#, 8 gaskets and 4 nuts, (the gaskets and nuts are on the back side as shown in ③④).















1. Use 24 screws 2# to install part #G3/G4 on both ends of the roof first (Note: Please follow the installation position as shown in the picture).



2.Install part #G7 at the joint of part #G3/G4, and fix it with 8 screws 2#, gaskets and nuts as shown in ③.



3.Part #G5/G6 is inlaid at the four corners and fixed with 8 screws 3#,16 gaskets and 8 nuts as shown in ①②.











Insert the bolt and lock the door

Open the door: insert the key, rotate 180° counterclockwise, and rotate the handle counterclockwise to open the door.

Lock the door: close the door, insert the key, rotate the handle clockwise, then rotate the key 180° clockwise and pull the key out.







Insert the bolt and locks the door



RESORT COMFORT IN YONR

OWN BACKYARD

Thanks for your purchase.

At domi outdoor living, we believe in our products.

That's why we provide a 12-month warranty and

friendly, easy-to-reach after-sales service. So if you

have any questions about our product and assembly-

,please feel free to contact us.We will be here for you.



email: service@domioutdoorliving.com

Please tell us your order ID when contact.

Attach photos of damaged part for instant reply.

Copyright 2019-2023 Domi Outdoor Living LLC. All Rights Reserved.