Domi outdoor living





Ф11'

SKU:LPBD0102

PATIO UMBRELLA

Assembly and Operation Manual

ECLIPSE SERIES

© Copyright 2023-2025 Domi Outdorr Living LLC. All Rights Reserved.

Thank you for your purchase of Eclipse Series Umbrella

Read and follow this assembly and operation guide.

To reduce personal injury and damage to your umbrella,

Please close your umbrella when it is incoming over 30 mph wind.

We recommend a two-person team for assembly and disassembly.

If you like our products, please tell other customers If you have problem with our products, please tell us

Please feel free to contact us.



A	Cantilevered Canopy	1X	В	Base Tube	1X
С	Base Cover	1X	D	Crank Handle	1X
Е	Connector Knob	1X	F	M8*30mm Bolt	4X
G	Flat Washer	4X	Н	Allen Wrench	1X
J	Protection Cover	1X	K	Collapsible Fiberglass Pole	1X
L	Solar Panel	1X	M	Battery	1X

Important

Prior to assembly, it is important to choose the location of the umbrella.

- •We recommend a **two-person team** for assembly and disassembly.
- •Allow **ample height** to avoid damage to your umbrella during assembly and usage.
- •Choose a location that is **level and sturdy**.
- •Consider a location that will maximize the umbrella's rotating swivel function. Placing the umbrella between two entertaining areas is ideal.
- To avoid personal injury or damage to the umbrella, make sure the **area** around you is **clear** from any outdoor structure or furniture.
- **Keep all the flame and heat sources away** from this umbrella.

STORAGE: Properly store the umbrella when not in use. Close the umbrella, fasten the strap around the canopy and cover the umbrella with a protective cover.

NOTE: DO NOT discard any packaging or box until assembly is complete.





CAUTION:


Moving the umbrella when it is fully open will increase the risk of damage to your umbrella or will cause serious injury.


ATTENTION:


Please remove the protective film prior to use












Solar panel Assembly


- 1.Insert the plug into the socket under the solar panel as shown below.
- 2.Put the solar panel on the top of umbrella and hide the plug and wire inside the groove at the top of umbrella. Then turn the solar panel clockwise.

Do not over tighten.

- 3.Put the solar umbrella in the sunlight to charge the battery for 8 hours before the first use.
- 4. You can get the battery out of the holder (hold the PUSH button), then charge it with USB wire.



Use the switch to turn on/off the LED light:



CAUTION:

YOU MUST CHARGE BATTERY BEFORE FIRST USE.

- Please note that battery can discharge if they are left unused or uncharged for a long period of time.
- Since there can be a six-month period between production and final customer purchase, we recommend you **charge your solar umbrella** for at least 8 hours in direct sunlight before the first use.
- Failure to charge the battery will result in premature dimming of the lights in your new solar umbrella.
- Make sure the **light switch is in the off position** when charging the solar panel. For everyday normal use, turn the light switch on at night when you want to use the solar light and turn off the switch after use.

MAKE SURE THE LIGHT SWITCH IS IN THE OFF POSITION IN THE DAYTIME FOR THE SOLAR PANEL TO RECHARGE THE BATTERY.


Umbrella Assembly

Two-persons recommended for team lift and to complete assembly.

Insert the **main pole** onto the **base tube #B** with the **base cover #C** in place.

Insert the **connector knob #E** to the matched up hole.

Please remove all of foam material from the frame before opening umbrella.



CAUTION: Stop turning the crank handle as soon as the umbrella cover is completely open and the sleeve on the umbrella pole has reached its maximum height.


IMPORTANT: PRIOR TO USING THE TILT FUNCTION.

To avoid personal injury or damage to the umbrella, make sure the area behind you is clear and free from any furniture or structure.

Slide the umbrella handle to the top of the pole by squeezing the trigger.




:Open the canopy a little and stop.



Note: Be mindful of the packaging in the umbrella canopy. It Must be removed before opening.




D




1X

Step 1:

Insert the crank handle #D into the small hole of the handle.



Step 2: Rotate the crank clockwise




To Tilt Canopy

Press on the handle trigger and move the handle up and down to adjust the angle of the umbrella canopy.


IMPORTANT: PRIOR TO USING THE TILT FUNCTION.


To avoid personal injury or damage to the umbrella, make sure the area behind you is clear and free from any furniture or structure.



To Operate The 360°Rotation


Insert the crank handle #D into the hole near the bottom of the umbrella, turn the crank to rotate it.





To Protect The Umbrella

- 1.Umbrella cover should only be used when umbrella fabric is completely dry.
- 2.Umbrella should be closed or stored indoors during windy conditions.
- 3.Do not use during windy or severe weather conditions.



WARRANTY

- This warranty is extended to the original purchaser and applies to defects in materials and workmanship of your patio furniture provided your furniture is maintained with care and used only for personal, residential purposes.
- The frame is warranted to be free from defects in material or workmanship for one (1) year.
- Fabric is warranted for a period of three(3) years. Fading or discoloration resulting from exposure to the elements, chemicals, or from spills is not covered.

SAFETY PRECAUTIONS

Close the umbrella in windy conditions or when a storm approaches.

Never allow the umbrella to flap in the wind. This could damage the canopy.

Properly store umbrella when not in use. Close umbrella, and cover umbrella with a protective cover.

Do not leave an open umbrella unattended. If damage occurs, this is not covered by the warranty.

When adjusting the umbrella, make sure that no person(s) or item(s) is close to the umbrella. This is important to prevent injury or material damage.

SAFETY PRECAUTIONS

When not in use, close and cover umbrella with a protective cover.

If necessary, clean the fabric with lukewarm water.

Allow a wet canopy to dry slightly opened, but do not leave unattended.

Wipe sliding marks on the aluminum poles with a damp cloth.

Winter Storage: Store in A Dry Place.



RESORT COMFORT IN YONR **OWN BACKYARD**





Business cooperation contact email:

marketing@domioutdoorliving.com

After-sales contact email:

service@domioutdoorliving.com

Please tell us your order ID when contact.

Attach photos of damaged part for instant reply.