## INSTRUCTION SHEET



## **REAR ACCESSORY ELECTRICAL HARNESS** FOR 2015-2018 POLARIS RZR

INCLUDED IN BOX: (1) Power Harness (1) Instruction Sheet

WARNING! Do not overload the vehicle's electrical system! QUESTIONS?

EMAIL: info@getklocked.com CALL: (605) 996.3700



- 1. Simply unplug the stock harness plug from the back side of the factory tail light.
- 2. Plug the female end of the harness back onto the tail light connector.
- 3. Plug the male end of the harness into the factory plug.
- 4. The pigtail leads wires get run to your LED whip light, lighted license plate, or third brake light.

BLACK WIRE = GROUND LEAD RED WIRE = RUNNING LIGHT / ACC 12V+ LEAD WHITE WIRE = BRAKE LIGHT 12V+ LEAD

A harness can be plugged in on each side of vehicle. This is recommended for low current lights or to trigger a relay for larger high power lights. If circuit is overloaded it could cause the fuse to blow or damage the OEM wiring.

Warning! Do not overload the vehicle's electrical system!

KLOCK WERKS // GETKLOCKED.COM