OIL COOLER GUARD FOR 2017+ H-D TOURING

TOOLS NEEDED:

INCLUDED COMPONENTS:

- No tools necessary
- + Oil Cooler Guard
- + Installation Instructions

QUESTIONS?


EMAIL:













1. Remove the oil cooler cover by pulling the two lower pins from the rubber grommets on the cooler and rotate forward to allow the top to be released from tabs. (FIG 1)

NOTE: The grommets may come out of the cooler and remain on the pins. If so, remove them from the cover and reinstall them into the cooler.

- 2. Install guard by fitting it over the top tabs on the oil cooler. (FIG 2)
- 3. Reinstall the cover over the top tabs, aligning the pins through the clearance holes it guards. Press the pins back into the rubber grommets in the cooler. (FIG 3)