



FABRIC SIGN GUYS

Flag Tensioning Guide



Too Loose: If your flag is not pulled down far enough on the pole it will cause Ripples and Creases to appear in the Flag. This can obstruct the Flag Artwork.



Too Tight: If your flag is pulled down too far on the pole it will cause it to bend and crease. This can obstruct the flag artwork and reduce the longevity of the flag.



Just Right: Your flag should sit flat with minimal ripples as shown. Hook the fabric loop to the locking mechanism and adjust it by twisting the nozzle to tighten. The locking mechanism should sit at approx. 15'7" from the base of the pole.

Step 1



Attach the fabric loop to the lock hook.

Step 2



Pull down the flag to the right tension. Refer to tensioning example.

Step 3



Twist the butterfly screw to secure the lock.