


Top View






Iso View

Side View




CW Morse 24 Series
PCB Straight Key

Dimensions



PCB STRAIGHT KEY SIGNAL DIAGRAM




JP1 NOTE:

When using a standard 3.5mm Stereo Aux Cable, some keyers, oscillators and software require that the RING and SLEEVE to be jumpered. (This allows for a straight key (mono) to be used with a stereo cable.)

CW Morse 24 Series
PCB Straight Key

Connections

Top View




CW Morse 24 Series
PCB Straight Key

Adjustments

Clean the Key using a dry paintbrush or compressed air.

Side View



How To Clean The Solid Brass Contacts:

Use a small strip of 220 grit sandpaper or Paper Nail File.

Close Contacts gently and Pull Sandpaper Through

Flip Paper Over And Repeat

CW Morse 24 Series
PCB Straight Key

Cleaning