

- 1. Attach the device-appropriate cable to the power bank output port, USB-C or USB-A. Note that the Ampex power bank supports charging speeds up
- 2. Connect the other side of the cable to your device.
- 3. Your device will begin charging immediately.
- 4. The Ampex power bank will indicate the remaining battery level via the battery level indicator lights on the front of the power bank.

#### CHARGING THE POWER BANK

- 1. Use the provided Micro-USB cable or USB-C cable and attach it to the input port on the power bank. 2. Connect the other end of the cable to any USB outlet on a Computer USB Öutlel computer, wall adapter
- [not included]. etc. (Fig.1 & 2) NOTE: Charaina while usina a USB wall adapter will be faster than a computer USB port.

Fig. 2

USB Wall

Adaptor

- **3.** The Ampex power bank will begin charging and indicate the remaining (not included) battery level via the battery level indicator lights on the front of the
- 4. All four battery indicator lights will appear solid when

NOTE: Recharge the battery immediately when battery level is low. Only one battery indicator light will be illuminated when the batteru is law.

5. When battery charging is complete, remove the provided Micro-USB cable or USB-C cable and store in a safe place for future use.

## AMPEX 2

# ≣ <mark>5,000mAh</mark> ≹ PORTABLE POWER BANK

### LIMITED LIFETIME WARRANTY

AMPEX products are covered by a Limited Lifetime Warranty against manufacturing defects in materials and workmanship for the lifetime of the product.

The life of the product can vary based on its age and how it is used. Items may be repaired or replaced at the discretion of AMPEX. If an identical product is not available, the most comparable product may be substituted, or credit towards a different AMPEX product may be offered.

If a product covered by this warranty fails due to a manufacturing defect, AMPEX will repair it without charge, or replace it, at the discretion of the manufacturer. Only oriainal. unaltered. and unmodified items and workmanship are covered. This warranty does not cover damage caused by accident, improper care, negligence, normal wear and tear, alterations, misuse, neglect, or the natural breakdown of colors and materials over extended time and use. Storm and wind damage, burns, UV damage, and products used for commercial use are specifically not covered. Damage not covered under warrantu mau be repaired for a reasonable rate and a fee may be charaed for shipping.

Service under this warranty is provided to the original consumer purchaser with proof of purchase from an AMPEX authorized dealer. AMPEX products purchased from unauthorized 3rd party retailers or in as-is or used condition are specifically not covered by this warranty. This warranty does not cover consequential damages, or any other losses caused bu anu defect in the product.

AMPEX products eligible for the Limited Lifetime Warranty are covered to the original owner, for the lifetime of the product. Please refer to the table below to assess the defined lifetime of products. To check availability and pricing for repairs or replacement parts, please call our customer support team at 1-877-887-8650 or email service@ampexgear.com.

C

RODUCT	PRODUCT LIFETIME DEFINITION & TERM	Distributed by I2D Licensed Brands
Portable Power Packs	Lifetime of the Product which, is Five (5) years from the original date of purchase of the Product by a customer from an AMPEX authorized dealer.	
	LERY.	whet

### SPECIFICATIONS

Capacity	5,000mAh	
input	Micro-USB: 5V/2A USB-C: 5V/3A, 9V/2A	
Cutput	USB-A: 5V/2A USB-C: 5V/3A, 9V/2A, 12V/1.5A	
Lublulu Size	114 x 66 x 12.7 mm / 4.5 x 2.6 x 0.5 in	
KG Weight	122 g / 4.3 oz	
WARNING!		

WARNING! Do not disassemble product. Do not charge the battery if the product / battery is cracked or damaaed. Do not short terminals, crush, heat above 140 Dearees F. (60 Dearees C.). throw into a fire. or incinerate. Please recucle.



s LLC. Overland Park. KS 66223 k of Insight 2 Design LLC.

Made in China, Printed in China