

## Compatible Routers:

|                           |                         |
|---------------------------|-------------------------|
| Bosch 1617 EVS            | Performax 241-1464      |
| Bosch 1617 EVSPK (Fixed)  | Porter Cable 100        |
| Bosch 1617 EVSPK (Plunge) | Porter Cable 690        |
| Bosch 1618 Series         | Porter Cable 690LR      |
| Bosch 1619 EVS            | Porter Cable 693LRPK    |
| Bosch MRF23EVS            | Porter Cable 7518       |
| Craftsman 315             | Porter Cable 7519       |
| Dewalt DW616              | Porter Cable 7529       |
| Dewalt DW616K             | Porter Cable 8529       |
| Dewalt DW618              | Porter Cable 890 Series |
| Dewalt DW6182             | Porter Cable 892        |
| Dewalt DW618B3            | Porter Cable 893PK      |
| Dewalt DW621              | Porter Cable 894PK      |
| Dewalt DW625              | Porter Cable 895PK      |
| Dewalt DWP611             | Porter Cable 9690       |
| Dewalt DWP611PK           | Porter Cable 9690LR     |
| Hitachi M12VC             | Ridgid R22002           |
| Makita 1100 Series        | Ryobi R163G**           |
| Makita 3620*              | Ryobi R163GK**          |
| Masterforce 241-0835      | Ryobi R1631K**          |

\*Interferes with Straight Edge Guide

\*\*Installs with 3 of the 4 baseplate screws. The 4th screw isn't necessary for full functionality and performance.

## Incompatible Routers:

|                 |                 |
|-----------------|-----------------|
| Festool 1010 EQ | Festool MFK700  |
| Festool 1400 EQ | Ryobi RE180PL1G |
| Festool 2200 EQ |                 |
| Festool 700 EQ  |                 |