

PARTS LIST

for

MAYTAG®


**COMMERCIAL
ELECTRIC DRYER**

**MODEL
MDE17CSAGW0**

TOP AND CONSOLE PARTS

For Model: MDE17CSAGW0

(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Model: MDE17CSAGW0
(White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	14	W10131123	Nut, #8 U Type	29	W10111029	Harness, Timer
	W10297242	Instructions	15	W10139210	Screw, 8-18 X 5/16	30	W10135270	Timer & Harness Assembly 50 Hz.
		Installation	16	W10135273	Panel, Rear (Upper)	31	W10145154	Cam, Commercial Lock
	W10163150	Wiring Diagram	17	3390647	Screw, 8-18 X 1/2	32	3351136	Door, Service
	W10184537	Repair Parts List	18	W10119283	Cover, Terminal Block	33	W10136649	Meter Case
2	W10146429	Nut, 8-32 X 3/8	19	W10223801	Screw, 8-18 X 3/8	34		Bolt, Meter Case Mounting
3	W10139799	Washer	20	717253	Receptacle (2-Way)		3353994	5/16-18 X 2 1/2
4	W10133502	Lens, Pilot Light Amber	21	357572	Clip, Ground		3349065	5/16-24 X 1.00
5	W10133507	Knob	22	3394427	Clip, Harness	35	3954812	Cushion, Meter Case
6	1188043	Relay, Heater 230V	23	717253	Receptacle (2-Way)	36	W10139060	Nut, 1/4-20
7	W10135190	Facia / Overlay	24	3391018	Tie, Cable	37	W10133509	Funnel, Coin
8	W10124213	Bracket, Control	25	351297	Plug, Harness	38	W10111042	Harness, Main
9	W10139100	Screw, 8-32 X 1/4	26	3936144	Connector 3-Circuit	39	W10136707	Top
10	W10137919	Switch, Cycle Selection	27	3395683	Housing, Connector	40	3347825	Plate Mounting (2)
11	W10181931	Switch, Push-To-Start	28	W10154739	Bracket, Timer	41	98445	Screw, 10-16 X 3/4
12	W10139459	Lamp-Indicator				42	W10153513	Extension
13	W10205153	Console				43		Timing Cam
							339855	Cam - 4 Pin
						44	W10140928	Clip, Knob

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

(White)



CABINET PARTS

For Model: MDE17CSAGW0

(White)

Illus. No.	Part No.	DESCRIPTION
1	3393008	Screw, 10-16 x 1/2
2	W10131123	Nut, #8 U Type
3	3391846	Clip, Front Panel (2)
4	3400077	Screw, 10-16 x 1/2
5	8318396	Foam-Seal
6	3397659	Block, Terminal
7	8310656	Cabinet
8	3392100	Foot, Dryer (Plastic)
	279810	Foot - Optional (Extended Length Package Of 2) (Not Included)
9	660658	Clamp, Motor (2)
10	3387374	Spring, Idler
11	W10080670	Screw
12	697750	Plug, Multivent
13	3388672	Pulley Assembly
14	3391915	Screw, 10-16 x 1
15	3394331	Plate, Cover
16	3394081	Wire, Belt Switch
17	8316644	Clip, Strain Relief
18	233520	Washer, Thurst
19	297092	Clip (2)
20	690997	Tri-Ring
21	3389247	Hinge And Pin (2)

Illus. No.	Part No.	DESCRIPTION
22	W10131119	Screw, 8-18 X 5/16
23	3391943	Boot, Foot
24	W10080540	Screw, 6-20 x 7/8
25	693152	Bumper
26	3389249	Nut, "U" (4)
27	3404470	Motor Assembly (50 Hz.)
28	3402548	Pulley
29	8533974	Screw, 10-32 x 1/2
30	W10131172	Belt, Drive
31	3390902	Clip, Door Hinge (2)
32	3387118	Bracket, Motor
33	3392186	Washer
34	279318	Terminal, Brass & Tinned (3) (Includes Ill. 35)
35	279393	Terminal Block Screw Kit (For Terminal Block)
36	3390663	Screw, 10-16 x 1/2
37	279731	4" - 90° Elbow
38	3393657	Restrainer, Belt
39	W10118754	Bracket, Idler
40	8318457	Switch-Belt
41	3406109	Door Switch Assembly

Illus. No.	Part No.	DESCRIPTION
42	W10118188	Screw, 6-20 x 1.00
43	697215	Panel, Toe
44	3387242	Seal, Front Panel
45	W10080310	Screw, 8-18 x 1/2
46	3388229	Retainer
47	3392563	Door, Rear
48	694091	Screw, 8-18 x 3/8
49	3387872	Door, Front
50	W10116360	Handle, Door
51	3393081	Front Panel
52	W10080240	Strike, Door
53	W10083220	Lever-Switch
54	3392538	Catch, Door Assembly
55	3390647	Screw, 8-18 x 1/2
56	3390735	Seal, Door
57	345670	Lock, Top
58	90406	Cage Nut
Optional Parts Not Included		
Dryer Exhaust Kit		
(For Side & Bottom Venting)		
59	279818	White

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

**For Model: MDE17CSAGW0
(White)**



BULKHEAD PARTS

For Model: MDE17CSAGW0

(White)

Illus. No.	Part No.	DESCRIPTION
1	8575324	Shaft, R.H. Thread
2	90767	Screw, 8-18 x 3/8
3	W10080820	Screw, 8-18 x 5/16
4	8066086	Drum Hole Plug
5	697354	Air Duct Assembly
6	697813	Foam-Seal
7	697814	Seal, Drum Front
8	W10080210	Nut 3/8 x 16 (R.H.)
9	W10121167	Exhaust Pipe
10	8572105	Clip
11	693995	Screw, 8-18 x 3/8
12	3392537	Box, Heater
13	3390647	Screw, 8-18 x 1/2
14	3387749	Element, Heater
15	W10049370	Screen, Lint
16	W10206200	Thermostat 155°F Electronic
17	3387809	Bulkhead, Rear
18	W10080960	Washer, Support
19	8575325	Shaft, L.H. Thread
20	690997	Ring, Tri
21	8536973	Roller, Support
22	697770	Foam-Seal
23	W10181927	Housing, Outlet
24	W10141623	Cut-Off, Thermal (Includes Illus. 32)
25	8528998	Drum Complete
26	W10219342	Screw, 11-16 x 3/4
27	W10166807	Seal, Drum
28	3394986	Spring, Lint Screen
29	W10119253	Bracket, Heater Box
30	W10167627	Thermal Limiter
31	487909	Screw, 8-15 x 1/2
32	W10168175	Thermostat 250°F
33	W10181926	Grill, Outlet
34	697557	Bulkhead, Front
35	697693	Baffle, Drum (3)
36	3357011	Screw, 10-16 X 1/2
37	W10168564	Wheel, Blower
38	W10181925	Door, Lint Screen
39	W10194158	Thermostat 140°F Cycling
40	W10080640	Screw, 10-16 x 3/4
41	W10151271	Housing, Blower
42	8066168	Lint Duct Assembly
43	8066208	Clip Spring
44	W10080190	Nut, 3/8-16 (L.H.)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Model: MDE17CSAGW0

(White)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

ACCESSORY PARTS

4392067 Kit,
Dryer Repair
8522199 Kit, Dryer
Vent Testing

PAINT, TOUCH-UP (1/2oz.)

72017 White

PAINT, PRESSURIZED SPRAY (12 oz.)

350930 White
350938 Primer, Gray

PAINT, BULK (1 qt.)

799344 White (Uncut)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST