



Q. MY TRIMMER IS OVERHEATING AND I HEAR A HUMMING NOISE FROM THE END OF THE TRIMMER.

HOW IT SHOULD LOOK



SOLUTION

1. Locate the motor side of the machine (area where it is humming) and remove the side cover and rear cover by removing the indicated screws.



2. Remove the two screws (pictured below) to adjust the height of the limit switch so that the limit switch will make contact with the cutting mechanism. The limit switch should click when it is engaged by the cutting mechanism, which will shut off the motor when the blade has reached the end of the machine.

