

## **MSI A3201 Motherboard Overview**



- MSI A3201 Motherboard has only one DMI port for the video signal.
- MSI A3201 uses DDR4 RAM instead of DDR3.
  - These RAM types are not compatible so be sure to specify your board type when ordering a replacement RAM.
- The hard drive is now located on the backside of the board.
  - You can remove the hard drive by removing the screw at one end and then sliding it out of the socket.
  - To install a new hard drive, slide it into the empty socket, alight it with the screw hole, and replace the screw.
- Instead of jumping the pins on the A3201, there is a button that comes off the board. Press the button to jump the pins.