

V7 Sport Headphones User Manual




Table of Contents

Getting Started	1
What we can do with the headphones	1
About the voice guidance	2
Charging your headphones	2
Parts and Controls	3
Location and function of parts	3
Making Connections	4
Pairing and connecting	4
Multipoint connection	5
Disconnecting Bluetooth connection	6
Initialize the headphones	6
Listening to Music	7
Controlling the audio device	7
About Phone Calls	8
Incoming call	8
Ending call	8
Connecting the Voice Assistant	9
Using the voice assist function (e.g.,Siri)	9
Important Information	10
How to wear	10
Parameters	10
Precautions	11
FAQs	12

Get Started

What we can do with the headphones

- Listening to music




- Talking on the phone



About the voice guidance

- 🔊 **Power on, Pairing** Turned on
- 🔊 **Power off** Turned off
- 🔊 **Pairing** Pairing mode
- 🔊 **Connected** Establish Bluetooth connection
- 🔊 **Disconnected, Pairing** Bluetooth is turned off


Charging your headphones



- The charging indicator (red) of the headphones lights up.
- Two hours after the headphones is fully charged, the indicator will turn blue automatically.

Parts and Controls

Location and function of parts






1. Power on / Power off / Volume up / Next song
2. Volume down / Previous song
3. Magnetic charging port
4. LED indicator
5. Multifunctional buttons: Pause / Play / Answer call / End call / Voice assistant
6. Microphone

Making Connections

Pairing and connecting

1. When powered off, press the power button for 3 seconds until the LED flashes blue, thus entering the Bluetooth pairing status.
2. Select "V7" on your device's Bluetooth list to connect.



	Flashing blue	Bluetooth pairing
	Blue indicator flashes every 5s	Bluetooth connected


Multipoint connection

- When successfully connected with the first device, turn on the Bluetooth of the second device to pair.

1




Phone 1



2




Phone 2



Disconnecting Bluetooth connection

- Turn off Bluetooth of device.
When disconnected, you will hear the voice guidance say, "Disconnected, Pairing".
- Turn off the headphones.
Press the "volume up" button for 5s, you will hear the voice guidance say, "Power off".

Initialize the headphones




Press "Vol+" and "Vol-" together for 5s to initialize the headphones

- Press the power button and the volume down button for 5s to clear the pairing information in shutdown status, the indicator will flash red and blue for one second.


Listening to Music

Controlling the audio device


- Play / Pause: Click the multi-function button once.



- Vol+: Press the "Vol+" to turn up the volume.
- Vol-: Press the "Vol-" to turn down the volume.



- The next Song: Long press "Vol+" for 2 seconds.
- The previous song: Long press "Vol-" for 2 seconds.




About Phone Calls

Incoming call

- Click the multi-function button to answer a call.
Press the multi-function button for 2s to reject a call.

Ending call


- Click the multi-function button to finish a call.



Connecting the Voice Assistant

Using the voice assist function (e.g.,Siri)

- Connect the headphones to the phone via Bluetooth connection.
- Double-click the multi-function button, when the phone is in standby or playing music.



Voice assistant (Siri) is activated

- Make a request to Siri while wearing the headphones on your ears.
- Double- click multi-function button again to exit Siri.

Important Information

How to wear



- Hang the headphones behind your neck with both speakers clinging to your cheekbones.
- Adjust it until you feel comfortable.

Parameters

Music play time	8 hours (70% volume)
Standby time	20 days
Charging time	2 hours
BT version.....	V5.3
Speaker impedance	16 Ω \pm 15%
Microphone sensitivity.....	42 \pm 3 db
Product weight	27g \pm 2g
Connection distance.....	15 meters
Charging voltage / current	5V / 0.5A

Precautions

- Please wear the headphones at your cheekbones before your ears and do not put them in your ears.
- Please use medium volume, preventing uncomfortable feeling from loud music for a long time.
- Please be alert to your surroundings, no matter how the volume is.
- The headphones should keep away from fire, water and high voltage devices.
- Children under three years old should be accompanied by their parents to use the headphones.
- Please do not treat it as household waste. Instead, send it to your Local electronic recycling center.

FAQs

Q: Why can't pairing be done?

A: Check that the headphones is on and the devices' Bluetooth is on.

If not, turn off the last connected Bluetooth device.

Q: Why is there a distorted sound?

A: Please keep the headphones away from a microwave oven, wireless LAN device, etc.

Q: Why the headphones does not operate properly?

A: Please initialize the headphones, if the headphones does not operate properly after you reset it.

Q: Why is the volume low when headphones' voice has been turned to the max?

A: Turn up the volume of the headphones and the connected device.

Please check that the "sync volume with phone" is turned on in your Android phone's Bluetooth settings.



ANCwear®

Dear Customer,

Thank you very much for choosing our Sport Headphones. ANCwear is always been committed to providing superior products and services. We hope that our products can not only meet your basic needs, but also bring more healthy and happiness to your life.

If you have any questions or suggestions regarding our products, please contact us! Highly appreciate getting your objective review. We will listen patiently and solve the problems whole heartedly.

Wish you all the best!

Yours sincerely,

ANCwear Service Team

Customer Support:



Support_UK@ancwear.com