


The original number is 0-0-0. To set your own combination, please follow these easy steps:




1. Keep the lock in the open position.
2. Push and hold the reset button on the bottom of the lock with a pen or a paper clip.
3. While holding the reset button, set your new combination by turning the dials. Be sure to remember your new combination.
4. Release the reset button and the setting is complete.

To reset a new combination, please repeat steps 1-4.

IMPORTED BY ACI BRANDS INC. 2616 SHERIDAN GARDEN DR.
OAKVILLE, ON., L6J 7Z2, CANADA MADE IN CHINA / FABRIQUÉ EN CHINE

Le code par défaut est 0-0-0. Pour régler votre propre combinaison, il vous suffit de suivre les étapes simples suivantes :



1. Tenir le cadenas en position ouverte.
2. Appuyer et maintenir le bouton de remise à zéro au bas du cadenas avec un stylo ou un trombone.
3. Tout en maintenant le bouton de remise à zéro enfoncé, créer la nouvelle combinaison en tournant les chiffres. Mémoriser la nouvelle combinaison.
4. Relâcher le bouton de remise à zéro, la nouvelle combinaison est créée.

Pour changer la combinaison à nouveau, refaire les étapes 1 à 4.

IMPORTÉ PAR ACI BRANDS INC. 2616 SHERIDAN GARDEN DR.
OAKVILLE, ON., L6J 7Z2, CANADA MADE IN CHINA / FABRIQUÉ EN CHINE