



MICRO PILOT ASSAULT KIT

OPERATOR'S MANUAL



ILLUSTRATION BY CHIZUWORKS

INTRODUCTION

The M-PAK (*Micro - Pilot Assault Kit*) is an urban, load-bearing device designed by M.RAGE ASTRAL SYSTEMS to sustain Pilots during urban combat operations. Taking the form of a lightweight, crossbody sling bag, the Micro-PAK features an impact and water-resistant 'M-PACT' hardshell that will ensure even the most delicate electronic equipment is kept safe in zero-gravitational environments...

FEATURES

- « Sleek, low-profile design with flexible and water-resistant hard shell.
 - « Secure, three-digit combination lock which keeps the bag securely closed in hostile environments. Programmable to any user combination on the fly.
 - « Emergency Power System which allows an electronic device to be plugged in, providing external charging to your device. **(Power Bank not included.)**
 - « Ambidextrous, removeable strap which can be attached to the left or right, depending on which shoulder the Pilot would like to use.
- Further customization options coming soon.
- « Exclusive, M-PAK Flight Tag



VIEW PRODUCT ON OUR WEBSITE
MDOTRAGE.COM



DESIGNED BY M.RAGE // ALL HYPE RESERVED...

M.RAGE
ASTRAL SYSTEMS



REPROGRAMMING LOCK MECHANISM

To adjust your lock combination, perform the following steps

1. To set the lock on your M-PAK, start with inputting the default combination code:
Default Combination Code: [0 0 0]
2. On the default combination code, press and hold the unlock button.
3. With the unlock button depressed, move the three numbers to the desired combination.
4. Once the desired combination has been set, release the unlock button.
Your lock has now been reprogrammed to the new combination.

[WARNING:] There is no reset function on the locking mechanism. If you forget your combination code, you will have to go through all of the numbers to reprogram your lock.

OPERATOR INSTRUCTIONS

M-PAK

USING THE "EMERGENCY POWER SYSTEM"

Learn how to utilize the USB Pass-through cable

« The M-PAK offers a USB Pass-through which allows you to charge your phone from the outside. This system is intended to offer charging capabilities with the bag while keeping cables and batteries organized. This also allows the bag to be closed and/or locked but still give the operator an option to charge their device.

NOTICE: This feature requires a USB power bank (*Not Included*)

USAGE INSTRUCTIONS

1. Simply plug your preferred, USB capable power bank into the bag using the internal USB plug located on the inside of the bag.
2. Plug the appropriate charging cable into the USB slot located outside of the bag.
3. Your device can now be plugged into the bag, providing external charging to the device.

[WARNING:] This bag CANNOT charge your device without plugging in a power bank. (*Not Included*)

