


ODYSSEY® PUTTING MIRROR INSTRUCTIONS

CONTENTS:

- A** Odyssey Putting Mirror
- B** (8) Alignment Pegs
- C** Cloth Carry Case


Before use, remove all protective wrapping from the putting mirror



INSTRUCTIONS:


STEP 1

1. Place putting mirror on flat surface (floor, carpet, putting green, etc.).
2. Make sure the right & left hand arrows are facing the target direction.



STEP 2


1. Place two (2) alignment pegs into the front ports** This will act as a "gate" to ensure a proper initial roll.
2. Set up remaining pegs into mirror holes that run along the arced red line. The red arc line will promote a proper putting path.




** When installing pegs, insert from the bottom of the mirror, up. The peg will slide up through the hole and will remain snug throughout use.

STEP 3

1. Use the double black line running down the center of the mirror as your target line. This line should be aimed at your target.
2. Set the ball in front of the center line of the mirror and align your shoulders to be parallel with the black line above the Left or Right hand indicators.



3. Your eyes should be directly over the ball and your putter head should be aligned with the double black line behind the ball.
4. If your putter knocks any of the alignment pegs out of their ports, then the swing path is incorrect.



NOTES:

- If you are using the putting mirror on a green, you can secure the mirror to the ground by placing tees through the holes into the turf instead of using the pegs.
- Cleaning the mirror: A household window cleaner and a cotton towel is recommended.