



HIGH FEATURE

- Die-cast aluminum lighting body
- Input 120V AC 50/60Hz
- Frosted PC lens
- ETL listed
- Design for standard United States junction box
- ORB colors body finishing
- CCT:3000K
- Suitable for Wet location
- Easy Installation
- Save energy



PRODUCT DIMENSIONS




customersupport@coloeur.com / (626) 699-4666

1

SPECIFICATIONS

Model No	COS802A
Wattage	3.5W
Voltage	120VAC/60Hz
LED Type	SM4020S35
Lumens	65lm(C0R8)
Color Temp	3000K
CRI	>90
Product weight	0.41lbs
Beam Angle	40°
Lifespan	50,000hrs
Working temp	-4°F-104°F
Body Material	Aluminum
Lens Material	PC
Cable Material	Copper
Wet Location	IP65

PHOTOMETRIC



customersupport@coloeur.com / (626) 699-4666

2

UNPACKING CHECK

PLEASE check and make sure that there are no signs of physical damage to the product when unpacking. DO NOT use damaged products.

WARNING

- All electrical connections must be made in accordance with local and National Electrical Code (N.E.C.) standards.
- ONLY use UL or IEC approved wires for the input/output connections.
- Due to the risk of fire or electrical shock, the installation of this product requires the knowledge of the electrical systems. If NO qualified. DO NOT attempt the installation and contact a qualified electrician.
- TURN OFF THE POWER before beginning the installation, inspection or removal.
- Use ALL necessary precautions while performing this procedure.
- IT IS IMPERATIVE THAT THE OUTLET BOX IS PROPERLY

GROUNDING

- DO NOT REVERSE THE LIVE AND NEUTRAL CONNECTIONS, OTHERWISE SAFETY WILL BE COMPROMISED
- The outlet box must be recessed in the wall and cannot be protruding from the wall.

NOTE: This is an integrated LED fixture, there are no bulbs to replace.




customersupport@coloeur.com / (626) 699-4666

3

PRODUCT DIAGRAM

- Outlet box (NOT INCLUDED)
- Mounting screws
- Mounting bracket
- Wire nuts
- Face plate
- Fixture wires
 - White fixture wire
 - Black fixture wire
 - Green fixture wire
- Supply wires
 - Neutral wire
 - Live wire
 - Ground wire



FIXTURE INSTALLATION

- Pull the power supply wires (7) out from the outlet box (1). Mount the mounting bracket (3) to the outlet box using the mounting screws (2).
- Use the wire nuts (4) to connect the fixture wires (6) to the power supply wires (7). (White-neutral, Black-live, Green-ground). Carefully tuck the wires inside the outlet box (1).
- Select the color temperature from 3000K, 4000K, and 5000K with the toggle switch.
- Snap the face plate (5) onto the fixture.
- Use sealant (not include), to fill the gap between the face plate (5) and the outlet box (1) to improve the water resistance.

customersupport@coloeur.com / (626) 699-4666

4

THANK YOU FOR CHOOSING COLUER

If you have any installation problems or need help
Call us! (626) 699-4666
Please do not hesitate to contact us:
✉ customersupport@coloeur.com


COLUER

3979 East Guasti Rd Unit A, Ontario, CA 91761

DIMMING

This product is compatible with most common residential typedimmers. Dimming performance will depend upon dimmer, dimmer settings (dimmers with adjustments to brightness range), wiring method, and the number of LED modules.

For best results, set dimmer position at maximum before adjusting to a lower light level. The following dimmers are recommended:
Lutron DV-600P, Lutron PD-6WCL, Lutron MACL-153M, Lutron-603p;
Leviton DSL06, Leviton RNL06.



customersupport@coloeur.com / (626) 699-4666

5

TROUBLE SHOOTING

If the fixture does not light:

- Check the power to see if it is on.
- Check STEP2 of the fixture installation, and make sure that all wire connections are connected properly.
- Check to see if the fixture is properly grounded.
- Check the switch to ensure that there aren't any defects.
- Check the fuse/circuit breaker for trips.

CLEANING AND MAINTENANCE

CAUTION:

Ensure that the fixture's temperature is cool enough to touch. DO NOT clean or perform maintenance while the fixture is energized.

- Clean the lens and fixture with a non-abrasive cleaning solution.
- DO NOT open the fixture to clean the LED bulb. DON NOT TOUCH THE LED BULB WHEN IT HOT.
- DO NOT SPRAY LIQUID DIRECTLY ON TO THE LEDs, LED driver or he wiring.

WARRANTY

5 years warranty

We warrant this light fixture against defects in material and workmanship for lifetime from the date purchase. If within this period the product is found to be defective in material or workmanship, this product must be returned with a copy of receipt as a proof purchase to the original place of purchase. The retailer will, at its option, repair, replace, or refund the purchase price to the original purchaser. Warranty does not include damages due to misuse, accidents, improper handling and /or installation, incidental, or consequential damages. As some states do not allow exclusions or limitations on the implied warranty, the above exclusions and limitations may not apply. This warranty gives you specific rights and you may also have other rights that vary from state to state.

customersupport@coloeur.com / (626) 699-4666

6



COLUER

USER MANUAL

COS802A
DIMMABLE LED
Indoor&Outdoor Step Light

www.coloeur.com