






Replacing and Installing Grand 20 Function Remote Control.


Step	Description	Tools	Picture
	Models that Apply: Elite Grand 4, 5, 5-LE, Pickle 3 Champion		
	<p>Unscrew the (4) screws that attach the control panel to the red case.</p>  <p>Control Panel - Open</p>		 <p>Control Panel - Open</p>
	<p>Take the plastic cover off of the Velcro, and stick it on the Left side of the case. (With the wires pointing toward the control panel).</p> 		 <p>Receiver being placed on Left hand side of the Red Case.</p>

Replacing and Installing Grand 20 Function Remote Control.

Connect the red and white wire (coupling) with the white female 4-pronged housing, into the Remote 4-pronged male connector jack.



Remote



Remote

Remote Receiver connected to Remote terminal on control panel.

Screw the control board back onto the case.



Control Panel - Open



Control Panel - Open