RABBIT

OVERVIEW

The Rabbit Fars™

All products by The Rabbit CompanyTM are made from soft, smooth, body safe materials.

Our easy to use interface allows users to easily find the right stimulation and intensity. Get ready for sensual satisfaction that can not be matched and will have you craving for more.





External Stimulator

Contro

LED Indicator

DC Charging Port

DC Charging Po



 Before first use, charge your rabbit for approximately 2 hours. The USB charging cable can be plugged into any USB port or USB/AC power adapter (not included).



Flashing Light = ChargingSolid Light = Fully Charged

 Rapid Flashing Light = Low battery, charge is needed

 Wash your rabbit with soap and water, or toy cleaner suitable for use with silicone items.



FAQs can be found at www.TheRabbitCompany.com Email us at customercare@TheRabbitCompany.com for any unanswered questions 3. Lubricate your rabbit (if needed) with a water based silicone compatible lubricant.

- 4. Turn ON your rabbit by pressing +
- 5. To change the vibration intensity, press and release + and -
- in the lowest level, press and hold - button for 3





CONTROLLING YOUR RABBIT

- · To turn the item ON press and hold +
- Press and release + to increase vibration intensity
- · Press and release to decrease vibration intensity
- · After the vibration is in the lowest level, press and hold button for 3 seconds, to turn it off.



CHARGING

- Insert the charging plug into the designated charging area
- Flashing light indicates item is charging
- Solid light indicates item is fully charged
- Rabbits require approximately 1.5 hours for full charge



Flashing Light = Charging






TRAVEL LOCK

- All rabbit items include travel lock for safe and convenient travel
- While the rabbit is powered OFF, simultaneously press and hold the + and buttons for 3 seconds. Flashing light will indicate the item is locked.
- To unlock simply press and hold the + and — again for 3 seconds. Flashing light will indicate lock is disabled





HARE CARE™

Cleaning, Storage & Safety

- 1. Always clean your Rabbit thoroughly before and after each use.
- We recommend using a premium water-based lubricant when needed. Silicone-based lubricants are not recommended and can cause damage to the product. Never use hand cream, or massage oils as lubricants for your intimate areas.
- 3. To properly clean your rabbit, use a suitable silicone-compatible toy cleanser. If this is not available, wash the silicone area of your rabbit with luke-warm water and an





antibacterial soap. Rinse clean and pat dry using a lint-free cloth or towel. Do not use cleaners containing alcohol, petrol or acetone.

- Avoid leaving your rabbit in direct sunlight and never expose it to extreme heat.
- 5. Waterproof function: The rabbit is not intended for extended or excessive submersion. After use in the bath or the shower, make sure to completely and throughly dry before storage. For best product performance, limit bathtub use to 15 minutes. Excessive or prolonged underwater exposure can lead to damage or failure of the



SPECIFICATIONS

Materials	Body Safe Abs / Silicone

149 x 26.1 x 31.6 mm

Use Time 1 hour

Charging

Weight 50 g

Li-ion 150 mAh

Max Noise Level <75 db

Interface

2 button interface

1.5 hours

10 modes

Size

Battery

DISPOSAL INFORMATION

Disposal of old electronic equipment (applicable in the EU and other European countries with separate waste collection systems):

The crossed-out dustbin symbol indicates that these items should not be treated as household waste, but rather brought to the appropriate collection point for recycling electrical and electronic equipment.









16

Complete user instructions in additional languages can be found at:

Designed and Developed by The Rabbit Company $^{\text{TM}}$

Made in China © The Rabbit Company™

www.TheRabbitCompany.com

FAQs can be found at www.TheRabbitCompany.com Email us at customercare@TheRabbitCompany.com for any unanswered questions_ The Delah it Common and