


THE
RABBIT
COMPANY™

OVERVIEW


All products by **The Rabbit Company™** are made from soft, smooth, body safe materials.

Our easy to use interface allows users to easily find the right stimulation and intensity. Get ready for sensual satisfaction that can not be matched and will have you craving for more.




The Prostate Rabbit™

THE PROSTATE RABBIT



WIRELESS REMOTE CONTROL




GETTING STARTED


1. Before first use, charge your rabbit for approximately 2 hours. The USB charging cable can be plugged into any USB port or USB/AC power adapter (not included).



- Flashing Light = Charging
- Solid Light = Fully Charged
- Rapid Flashing Light = Low battery, charge is needed

2. Wash your rabbit with soap and water, or toy cleaner suitable for use with silicone items.




3. Lubricate your rabbit (if needed) with a water based, silicone compatible lubricant.

4. Turn ON your rabbit by pressing  quickly at the bottom of your rabbit. The light will flash, indicating the power is on and in standby mode.

Push  again on your rabbit to use the manual mode, or push  on the remote to pair the remote & rabbit.

Once in use, the base light will change from flashing to solid.





FAQs can be found at
www.TheRabbitCompany.com




Email us at
customer@TheRabbitCompany.com
for any unanswered questions

5. To change the vibration pattern via the base control, press the .

6. To change the vibration intensity via the remote control press and release **+** (Increase Intensity) and **-** (Decrease Intensity).











MANUAL CONTROL


1. To turn the item ON quickly press  on your rabbit. The  will flash to indicate the power is on. Push  again to change the vibration pattern. There are a total of 6 modes using the manual control.

2. To power OFF your rabbit press  and hold for 2 seconds. LED will turn off to indicate the power is OFF.









REMOTE CONTROL

1. First turn your rabbit on in standby mode by quickly pressing  on the bottom of your rabbit.
2. While the baselight is flashing, press  to power on your remote to pair the remote & rabbit.
3. Once the item is paired the base light  will become **solid** and you can control your rabbit by remote.
4. Press and release  on the remote to increase vibration intensity.
5. Press and release  on the remote to decrease vibration intensity.
6. To change the independent vibrator in the prostate/anal massager, press and release .
7. Holding  for 3 seconds will turn off the independent prostate/anal massager. Holding  for 3 seconds will



turn on the independent prostate/anal massager.

8. To change the individual vibrator in the rabbit attachment (clitoral/perineum stimulator), press and release .
9. Holding  for 3 seconds will turn OFF the independant rabbit vibrator. Pressing and releasing  will turn it back ON.
10. To turn the item ON/OFF press and release  on the remote.
11. To completely turn off your rabbit, press and hold  on your rabbit.




CHARGING

- Insert the charging plug into the designated charging area

- Flashing light indicates item is charging

- Solid light indicates item is fully charged

- Rabbits require approximately 2 hours for full charge



Flashing light = Charging



Solid light = Fully Charged




CHANGING YOUR REMOTE CONTROL BATTERY

- Slide open the remote control battery compartment as shown.

- Button cell CR 2032 has been preinstalled into the remote control.

- Remove the paper slip inside the battery compartment to activate the power in the remote control.

- Suggested to remove the battery from the remote control for extended storage. Store the remote control and the battery separately.



TRAVEL LOCK



• The Rabbit Company™ items include a travel lock for safe and convenient travel.


For the remote:

Simultaneously press and hold the + and – buttons for 3 seconds. Flashing light will indicate the item is locked.


To unlock simply press and hold + and – again for 3 seconds. Flashing light will indicate lock is disabled.

For the rabbit:

Hold  for 5 seconds, flashing light will indicate the item is locked. For unlocking, hold  again for 5 seconds, flashing light will indicate the item is unlocked.



VIBRATING MODES




HARE CARE™

Cleaning, Storage & Safety

1. Always clean your rabbit thoroughly before and after each use.

2. We recommend using a premium water-based lubricant when needed. Silicone-based lubricants are not recommended and can cause damage to the product. Never use hand cream, or massage oils as lubricants for your intimate areas.

3. To properly clean your rabbit, use a suitable silicone-compatible toy cleanser. If this is not available, wash the silicone area of your rabbit with luke-warm water and an antibacterial soap. Rinse clean and pat dry using





a lint-free cloth or towel. Do not use cleaners containing alcohol, petrol or acetone.

4. Avoid leaving your rabbit in direct sunlight and never expose it to extreme heat.

5. Our products are designed to be splash-proof. Never immerse your rabbit in water.

If your rabbit appears to function abnormally, turn OFF and consult our customer care section on **TheRabbitCompany.com** where you will find help tips. Should you require further assistance please contact:

customercare@TheRabbitCompany.com



SPECIFICATIONS

Materials	Body Safe Abs / Silicone
Size	102 x 107 x 39 mm
Weight	130 g
Battery	Li-ion 720mAh
Charging	2 hours
Use Time	1 hour
Max Noise Level	< 68 dB
Interface	Single Button Manual Control 5 Button Remote Control
Modes	12

DISPOSAL INFORMATION

Disposal of old electronic equipment (applicable in the EU and other European countries with separate waste collection systems):



RoHS
2002/95/EC



The crossed-out dustbin symbol indicates that these items should not be treated as household waste, but rather brought to the appropriate collection point for recycling electrical and electronic equipment.

Complete user instructions in additional languages can be found at:

www.TheRabbitCompany.com

Sold as a novelty only. Made and packed in China. All rights reserved. The shape and appearance of the products in this guide are a trademark and trade dress of B.C.B.V.I © B.C.B.V.I

Visit www.trcpatents.com for more info.

FAQs can be found at
www.TheRabbitCompany.com

Email us at
customercare@TheRabbitCompany.com
for any unanswered questions

Warning: This product is for adults only. To avoid injury or aggravation of pre-existing conditions, this device should not be used on swollen or inflamed areas, or skin lacerations. No medical claims are warranted or implied by the use of this product.

Designed and Developed by
The Rabbit Company™

Made in China
© The Rabbit Company™

TheRabbitCompany.com