


## OVERVIEW

All products by **The Rabbit Company™** are made from soft, smooth, body safe materials.


Our easy to use interface allows users to easily find the right stimulation and intensity. Get ready for sensual satisfaction that can not be matched and will have you craving for more.

2

## THE REMOTE CONTROL BUTTERFLY PANTY VIBE




## THE BUTTERFLY PANTY VIBE



4

## WIRELESS REMOTE CONTROL




5

## GETTING STARTED


1. Before first use, charge your butterfly vibe for approximately 15 hours. The USB charging cable can be plugged into any USB port or USB/AC power adapter (not included).


- Flashing Light = Charging
- Solid Light = Fully Charged
- Rapid Flashing Light = Low battery, charge is needed

2. Wash your butterfly vibe with soap and water, or toy cleaner suitable for use with silicone items.




3. Lubricate your butterfly vibe (if needed) with a water based, silicone compatible lubricant.

4. Turn ON your butterfly vibe by pressing  quickly. The light will flash, indicating the power is on and in standby mode.

Push  again on your butterfly vibe to use the manual mode, or push + on the remote to pair the remote & butterfly vibe.


Once in use, the light will change from flashing to solid.




FAQs can be found at [www.TheRabbitCompany.com](http://www.TheRabbitCompany.com)

Email us at [customer@TheRabbitCompany.com](mailto:customer@TheRabbitCompany.com) for any unanswered questions

7

- To change the vibration pattern via manual control, press the .
- To change the vibration intensity via the remote control press and release **+** (Increase Intensity) and **-** (Decrease Intensity).








### HOW TO USE YOUR BUTTERFLY PANTY VIBE

Assemble the three adjustable and removable waist and thigh straps (1xwaist, 2xthigh) to butterfly vibe, and dress up accordingly as photo shown while the ON/OFF button faces outside.






### MANUAL CONTROL






- To turn the item ON quickly press  on your butterfly vibe. The  will flash to indicate the power is on. Push  again to change the vibration pattern. There are a total of 15 modes using the manual control.
- To power OFF your butterfly vibe press  and hold for 2 seconds. LED will turn off to indicate the power is OFF.




### REMOTE CONTROL

- First turn your butterfly vibe on in standby mode by quickly pressing  on your butterfly vibe.
- While the light is flashing, press **+** to power on your remote and to pair the remote & butterfly vibe.
- Once the item is paired, the light on the butterfly vibe () will become **solid** and you can control your butterfly vibe by remote.
- Press and release **+** on the remote to increase vibration intensity.
- Press and release **-** on the remote to decrease vibration intensity.




- To change the vibration pattern, press and release  on the remote.
- Holding  for 3 seconds will pause vibration. Quickly pressing  resumes vibration.
- To turn the item ON/OFF press and release  on the remote.
- To completely turn off your butterfly vibe, press and hold  on your butterfly vibe.




### CHARGING

- Attach the magnetic charging plug to the designated charging area on the base of the product.
- Flashing light indicates item is charging
- Solid light indicates item is fully charged
- The butterfly vibe requires approximately 1.5 hours for full charge



Flashing light = Charging




Solid light = Fully Charged



### CHANGING YOUR REMOTE CONTROL BATTERY

- Use a coin to open the cover by placing it in the slit at the center of the battery cover. Rotate until the battery cover is removed. Open the battery compartment.
- Button cell CR 2032 has been preinstalled into the remote control.
- Remove the paper slip inside the battery compartment to activate the power in the remote control.
- Store the remote control and the battery separately to prolong the battery life.



## TRAVEL LOCK



The Rabbit Company™ items include a travel lock for safe and convenient travel


### For the remote:

Simultaneously press and hold the + and - buttons for 3 seconds. Flashing light will indicate the item is locked.

To unlock simply press and hold + and - again for 3 seconds. Flashing light will indicate lock is disabled.


### For the butterfly vibe:

Hold  for 5 seconds, flashing light will indicate the item is locked. For unlocking, hold  again for 5 seconds, flashing light will indicate the item is unlocked.



14

## VIBRATION PATTERNS




15

## HARE CARE™

### Cleaning, Storage & Safety

1. Always clean your butterfly vibe thoroughly before and after each use.
2. We recommend using a premium water-based lubricant when needed. Silicone-based lubricants are not recommended and can cause damage to the product. Never use hand cream, or massage oils as lubricants for your intimate areas.
3. To properly clean your butterfly vibe, use a suitable silicone-compatible toy cleanser. If this is not available, wash the silicone area of your butterfly vibe with luke-warm water and an antibacterial soap. Rinse clean and pat dry using a lint-free cloth or towel. Do not use cleaners containing alcohol, petrol or acetone.




4. Avoid leaving your butterfly vibe in direct sunlight and never expose it to extreme heat.

5. Our products are designed to be splash-proof. Never immerse your butterfly vibe in water.

If your butterfly vibe appears to function abnormally, turn OFF and consult our customer care section on [TheRabbitCompany.com](http://TheRabbitCompany.com) where you will find help tips. Should you require further assistance please contact:

[customercare@TheRabbitCompany.com](mailto:customercare@TheRabbitCompany.com)



16

17

## SPECIFICATIONS

**Materials**  
Body Safe Abs / Silicone

**Size**  
Butterfly: 58 x 72 mm  
Remote: 37 x 69 mm

**Weight**  
Butterfly: 40g  
Remote: 20g

**Battery**  
Li-ion 200 mAh

**Charging**  
1.5 hours

**Use Time**  
1 hour

**Max Noise Level**  
<68 db

**Interface**  
15 vibration patterns

## DISPOSAL INFORMATION

Disposal of old electronic equipment (applicable in the EU and other European countries with separate waste collection systems):

The crossed-out dustbin symbol indicates that these items should not be treated as household waste, but rather brought to the appropriate collection point for recycling electrical and electronic equipment.



18

## RED DECLARATION

### EC Declaration of Conformity

In accordance with EN ISO 17050-1:2004

We: XGEN, LLC  
of: Horsham, PA 19044

in accordance with the following Directive(s)

2014/53/EU Radio Equipment Directive (RED)

hereby declare that:

Equipment: BUTTERFLY PANTY VIBE  
RABBIT

Branded:

Model No: TRC-030PUR

is in conformity with the applicable requirements of the above directives and the following documents

ETSI EN300 220-1 V3.1.1(2017-02) ETSI EN300 220-2 V3.2.1(2018-06)  
ETSI EN301 489-1 V2.2.3(2019-11) ETSI EN301 489-3 V2.1.1(2019-03)  
EN62479:2010; EN50663:2017

Signed:

Name: G. Greene  
Position: Manager  
Date: 01 January 2021

19