

What do the lights mean?



Flashing Blue

Waste drawer full



Solid Yellow

Robot cycling



Solid Red

Cat detected and wait time countdown initiated
No action required or press Reset to cancel timing



Solid Blue

Robot ready for use



Solid Blue & Yellow

Sleep mode enabled, within specified sleep time



Flashing Yellow

Cycle interrupted or bonnet removed
Check for excess litter or check bonnet



Flashing Red

Cat sensor fault
Check for excess weight (such as too much waste or litter) and press Reset

Quick start guide.

litter-robot
by whisker



What's in the Box



Carbon filter



AC/DC power supply




(3) Waste drawer liners



Accessories
(optional – sold separately or in bundle)

Need help? Visit catevolution.com.au

LRS-8010-0g



Never push the Litter-Robot against a wall or into a corner (must not be touching any walls).

Cats must weigh at least 2.5kg to safely use the Litter-Robot in Automatic Mode.




For a complete guided online experience and tips on acclimating your cat, please visit catevolution.com.au

Control panel icons



Power

- ✓ Press and release the Power button  to turn the robot ON or OFF. The robot will begin a clean cycle when power is turned on.
- ✓ Press and hold, while at the home position, to enter night light setting mode.

Cycle

Cycle

- ✓ Press and release the Cycle button to start a clean cycle.
- ✓ If already cycling, press Cycle to pause; press again to resume a cycle.
- ✓ Press and hold, while at the home position, to enter sleep mode.

Empty

Empty

- ✓ Press and release the Empty button to start an empty cycle (empties all litter into the waste drawer).
- ✓ If already cycling, press Empty to pause; press again to cancel a cycle.
- ✓ Press and hold, while at the home position, to enter wait time setting mode.

Reset

Reset

- ✓ Press and release the Reset button to reset the cat sensor. (Do this after emptying the waste drawer, adding litter, etc.)
- ✓ If already cycling, press Reset to pause; press again to cancel a cycle.
- ✓ Press and hold, while at the home position, to enter control panel lockout.

1

Ensure proper placement



- ✓ If possible, place the Litter-Robot in the same location as the old litter box (at least during transition).
- ✓ Make sure the unit is indoors on a firm, level surface and in a cool, dry location.
- ✓ Place litter mats or rugs in front of the unit.

2

Add litter



- ✓ Use clumping litter or litter beads and crystals that are small enough to pass through the screen.
- ✓ Add litter until it meets the raised fill line when spread flat (8-10 lbs or **4kg**). Be careful not to overfill.



3


Power on



- ✓ Insert the small plug end of the power cord into the socket on the back of the base.
- ✓ Plug the AC/DC adapter into a wall outlet.
- ✓ Press the Power button on the control panel.

4

Download the app



- ✓ **Litter-Robot Connect units only – look for the WiFi symbol on the control panel.** Download the Whisker app and follow the onboarding instructions.

