
Shelf support - for wooden shelves H 30 mm


VE80MPFER030AB

PACKING

- 1 box:
- 120 shelf supports
- 120 supports for cabinet side
- 1. Screw-fix the supports to the cabinet side with EUROSCREWS TPS Ø 6.3 x 14 Z.B.




3. Press down firmly to lock the shelf in position




2. Drill the shelf with a **ø 30 mm** hole.

Insert the shelf support in the hole and fix with WOOD screws

TC Ø 4 x 30 Z.B.



4. Use a screwdriver here to release the shelf




Shelf support - for wooden shelves H 35 mm


VE80MPFER036AB

PACKING


- 1 box:
- 120 shelf supports
- 120 supports for cabinet side
- 1. Screw-fix the supports to the cabinet side with EUROSCREWS TPS \emptyset 6.3 x 14 Z.B.



3. Press down firmly to lock the shelf in position



2. Drill the shelf with a \emptyset 32 mm hole. Insert the shelf support in the hole and fix with WOOD screws TC \emptyset 4 x 30 Z.B.



4. Use a screwdriver here to release the shelf

