

## Generic Replacement Cell for Resilience Cell Cell Connector Conversion Kit Instructions

The Resilience chlorinator system is available in two different cell connector configurations. The first configuration is the cell with quick connectors. The second configuration is the cell with connector pins. Your generic replacement cell will come factory built in the first configuration - with quick connectors. To use the replacement cell for the second configuration the Cell Connector Conversion Kit needs to be used as instructed below.

