

Remote Control Code for ETOE E2 Pro

No.	Key Name	Infrared key	HID HID key code value table	
			Usage Page	Usage ID
1	Power	0x0A	NA	NA
2	Mute	0x0D	0x0C	0x00E2
3	OK	0x1F	0x0C	0x0041
4	Up	0x00	0x0C	0x0042
4	Down	0x01	0x0C	0x0043
4	Left	0x03	0x0C	0x0044
4	Right	0x02	0x0C	0x0045
5	Back	0x1C	0x0C	0x0224
6	Google Assistant	0x2E	0x0C	0x0221
7	Home	0x2E	0x0C	0x0223
8	Vol+	0x58	0x0C	0x00E9
8	Vol-	0x5D	0x0C	0x00EA
9	Netflix	0x4E	0x0C	0x0008
10	Prime Video	0x2E	0x0C	0x003E
11	Projector Focus	0x74	NA	NA
12	Projector Home	0x08	NA	NA

