

**SIM-3630, SIM-3933, SIM-4236, SIM-4842**  
**Installation Instructions**



Leave this manual with party responsible for use and operation.

**CAUTION! Risk of Cuts, Abrasions or Flying Debris.** Wear protective gloves and safety glasses during installation. Sheet metal edges are sharp.

**DANGER**



**HOT GLASS WILL CAUSE BURNS.**

**DO NOT TOUCH GLASS UNTIL COOLED.**

**NEVER ALLOW CHILDREN TO TOUCH GLASS.**

A barrier designed to reduce the risk of burns from the hot viewing glass is provided with this appliance and shall be installed for the protection of children and other at-risk individuals.

**WARNING! Risk of Fire! Combustible materials MUST NOT overlap or be placed under a surround.**

**CAUTION! Do not install damaged components.**

**WARNING! Risk of Fire! DO NOT** apply combustible materials beyond the minimum clearances. Comply with all minimum clearances to combustibles as specified. Overlapping materials could ignite and will interfere with proper operation of doors and louvers.

**For Models:**

**NDV3630I-B, NDV3630IL-B, NDV3933I-B, NDV3933IL-B, NDV4236I-B, NDV4236IL-B, NDV4236I-NVR, NDV4842I-B, NDV4842IL-B, NDV30-IFT, NDV30L-IFT, NDV33-IFT, NDV33L-IFT, NDV36-IFT, NDV36L-IFT, NDV36-IFT-NVR, NDV42-IFT, NDV42L-IFT**

**NBV3630I-B, NBV3933I-B, NBV4236I-B, NBV4842I-B, NBV30-IFT, NBV33-IFT, NBV36-IFT, NBV42-IFT**

**NNXT3933IF-B, NNXT3933ILF-B, NNXT4236IF-B, NNXT4236ILF-B, NNXT33-IFT, NNXT33L-IFT, NNXT36-IFT, NNXT36L-IFT**

**CONTENTS:**

- Decorative Front Assembly
- Shoulder Screws (2)
- Installation Instructions

**PREPARATION:**

- Verify and remove contents from packaging before beginning installation.
- Refer to cleaning instructions on page 3.

**TOOLS REQUIRED:**

- 1/4 inch drill driver with 1/4 hex bit

Proceed to “Install Hood.”

For the models listed below, it will be necessary to remove the lower magnet latches and replace with a shoulder screw:

**NDV3630I, NDV3630IL, NDV3933I, NDV3933IL, NDV4236I, NDV4236IL, NDV4842I, NDV4842IL**

**NBV3630I, NBV3933I, NBV4236I, NBV4842I**

**NNXT3933IF, NNXT3933ILF, NNXT4236IF, NNXT4236ILF**

**TOOLS REQUIRED:**

- 1/4 inch drill driver with #2 Phillips bit and 1/4 hex bit

**CONTENTS:**

- Decorative Front Assembly
- Hood

**PREPARATION:**

- Verify and remove contents from packaging before beginning installation.
- Refer to cleaning instructions on page 3.

1. Locate the magnetic latches in the bottom corners of the appliance. Using a #2 Phillips bit, remove the two screws retaining both latches. See Figure 1.



**Figure 1. Remove Screws from Magnetic Latches**

2. Install a shoulder screw in the outermost hole from where the latches were removed. See Figure 2. Shoulder screws are located in the manual bag. Tighten shoulder screw until snug. Do not overtighten.




Figure 2. Install Shoulder Screw (1 Per Side)

### INSTALL HOOD (All Models)

1. Locate the four screws inside the upper section of the appliance.
2. Loosen and partially unscrew all four screws about 1/8 inch using a 1/4 inch drill driver.
3. Slide the hood into position under the screw heads. See Figure 3.
4. Using a 1/4 inch drill driver, tighten the four screws. Do not overtighten.



Figure 3. Install Hood

## INSTALL THE SIMON DECORATIVE FRONT

(All Models)

1. Check that the hanging brackets are bent to an approximate 90 degree angle as shown in Figure 4.



Figure 4. Hanging Hooks Bent Correctly

2. Install the decorative front by hanging it on the four shoulder screws on the appliance. See Figure 5.

**Note:** It may be necessary to adjust the hanging brackets slightly to make the decorative front hang squarely in the appliance opening.



Figure 5. Hang Decorative Front on Shoulder Screws

### Cleaning Instructions for Decorative Fronts

Use a microfiber cloth and Windex® Original Glass Cleaner or 03M003 Stove Bright® Glass Cleaner to clean the decorative front immediately after installation to remove acids deposited by the installer or technician. Spray the cleaner onto the microfiber cloth and carefully wipe the entire surface. The decorative front should be cleaned in this manner annually by the homeowner to remove fingerprints or other contaminants. Once oxidation of the paint pigment has occurred, cleaning will not restore the original color.

Please contact your Heatilator dealer with any questions or concerns.

For the location of your nearest Heatilator dealer, please visit [www.heatilator.com](http://www.heatilator.com).

Heatilator, a brand of Hearth & Home Technologies  
7571 215th Street West, Lakeville, MN 55044  
[www.heatilator.com](http://www.heatilator.com)