

# Utility Output 2

- Pre-Defined (0AU) to activate a Strobe, (Follows Partition/Strobe Trigger/Latched N/O)
- A maximum of 100mA may be drawn from this terminal

