


Crescent

Rocker chair

<del>.</del>ක—

可瑞森摇椅



# IMPORTANT: PLEASE READ THE INSTRUCTIONS CAREFULLY AND KEEP FOR FUTURE REFERENCE

重要:请仔细阅读此说明书,并妥善保管以便日后参考。

Boori Australia Pty Ltd Boori (Europe) Ltd 18-20 Charles Street St. Marys Sydney NSW 2760 Australia

Tel: 61 2 9833 3769 Fax: 61 2 9673 4240 www.boori.com.au

www.boori.co.uk

Unit 1 Riverside House, Mill Lane, Newbury, Berkshire, RG 14 5QS Tel: (44) 016 3529 5670 Fax: (44) 016 3587 7552

## Halim & Boori Company 10F. Halim INT'L B/D, #1674-4,

Seocho-Dong, Seocho-Gu, Seoul, Korea Tel: +82-2-598-1470

Fax: +82-2-583-8885 E-mail: ted@boori.co.kr Postal code: 137-725.

### ブーリジャパン(株)

〒541-0057

日本国大阪府大阪市 中央区北久宝寺町4-2-10

Tel: 06-4963-3939 Fax: 06-4963-3900 E-mail: info@boori.co.jp

# 博瑞儿童用品(上海)有限公司

上海市青浦区徐泾镇华徐公路577号

VEG微格创意园A8-10室

邮编:201702 电话: 021-52966600 传真: 021-52966636 网址: www.boori.com.cn

# **Crescent Rocker chair** (BK-CRRC)


Dimensions/产品规格: 687mm\*859mm\*792mm

Main Materials/主要材质: European Beech、Plywood/欧洲榉木,实木多层板

# Hardware / 五金单


Α	B x 12	C x 12	D x 4	E x 4	Fx8	G x 4
			M6*14mm	M6*13mm	M6*47mm	M6*60mm


# Parts List / 部件清单





NOTE: Use only spare parts approved by the manufacturer.

注意: 仅使用制造商提供的零部件及五金。











# Kids Furniture Care Instructions

We hope you love your new Boori Kids furniture and it becomes an important part of your family home. In order to keep your furniture looking its best, please follow these care instructions.

# Assembly

- When assembling your furniture, please follow the assembly instructions and use the tools supplied
- Boori products should only be assembled by an adult away from children
- Heavy components should be lifted by two people to prevent injury
- Every section that is assembled should be checked after assembly before moving onto the next stage

# **Product Positioning**

- This product is made of timber and is therefore flammable
- Do not place your Boori furniture near open flames, fire places or extreme heat sources such as electric or gas heaters
- Do not direct sprayers or humidifiers at the furniture as they can cause damage
- Where possible avoid exposing furniture to extreme changes in temperature. Timber is a natural product and will want to expand and contract as the temperature varies. Extreme temperature variations can damage timber products.
- Avoid direct exposure to sunlight as this can cause our natural timber and plant oil colours to fade.
- Black rubber feet on items such as radios, computers and picture frames can cause marks. Always use a felt mat (not plastic) to protect your Boori furniture
- Do not place in damp environments or areas with high levels of moisture as this encourages mould growth.

# Cleaning

- Clean your furniture by wiping with a soft, damp cloth
- If necessary, use a mild soapy solution and wipe clean with a soft cloth
- Do not use strong household cleaners
- Always wipe in the direction of the wood grain, not in circles.
- Wipe up spills immediately with a soft cloth
- Protect the furniture against bedwetting as this can lead to discolouration

#### Maintenance

- We advise that you regularly check the safety of your furniture
- Ensure all bolts and screws are tightened and check for loose connections, missing parts or sharp or pointed edges
- · Avoid contact with sharp objects and hot liquids
- When moving furniture always lift and place it into position; do not drag. We recommend that two people lift or alter the positioning of the furniture

# **Product testing Standards**

• Standard: GB 28007-2011 EN 747-1: 2012+ A1: 2015 AS/NZS 4220: 2010