



## KARMA CANVAS NOMAD FLASHING KIT INSTRUCTIONS

Before fitting your flashing kit, you will need to cut the silicone to size along the pre-marked line. For double insulated flues, this will be the 90mm line.



Carefully cut the flashing kit along the appropriate line with a sharp pair of scissors - a Stanley knife can also be used if you are very careful.

If you are using a Karma Canvas double insulated section, you will need to measure approximately 90mm hole and cut at this line.

**Try to make the cut as neat and straight as possible to eliminate any chance of splitting.**



Position your stove in the tent where you would like it to be. If using a pre-cut hole / stove jack, this step is not required as you will use the pre-prepared area.

Take the flashing kit apart and place one of the metal flashing rings up against the canvas on the inside (where the flue exits) and mark every hole, including the large central one.

Then, with a very sharp blade, make incisions for the screw holes only.



Next, go outside the tent and attach the flashing kit by hanging the first ring and silicone collar on the outside of the canvas (see picture) Push through the bolts from the outside. Go back inside the tent and clamp the second ring on the inside using the nuts provided.



Push the double insulated section through the flashing from the inside. It may help to use a little water and dish soap to lubricate the flue and make it easier to push through.

Fit the remaining flue sections and spark arrestor into the stove.

Check to make sure everything is stable and pushed together firmly.

Light your stove and get cosy!



- It is possible to install the Nomad Flashing Kit alone but is easier with two.
- Ensure the stove body sits at least 1 metre below the flashing kit to reduce heat damage.
- Please place your stove on a fire-retardant heat mat or surface inside the shelter in case of stray embers.
- On your first burn, please ensure that the shelter is well ventilated, to allow any fumes caused by the factory protective coating to escape, or do the first burn outside.

**Karma Canvas accepts no responsibility for the use or misuse of the Nomad Stove or its flashing kit.**

**We only recommend this item for use with Karma Canvas products. It is the end-user's responsibility to ensure that appropriate safety measures are adhered to when using this product or any other Karma canvas product.**

**We advise not to leave any stove unattended in the shelter and to ensure it has been extinguished prior to going to sleep or leaving the shelter for long periods.**

**Always make sure the stove is positioned on a heat mat.**

**Always ensure you have a fire extinguisher to hand or at a very minimum, a bucket of water filled and ready for any eventuality when using any stove or fire inside a shelter.**

**We strongly advise that you always use a portable carbon monoxide alarm when using a stove inside a shelter of any kind.**