2022 SaberCustom Lightsaber RGB-X User Manual

In this Manual, every 1 flash=0.5 seconds (For those lightsabers with hidden button/no-light button)

Awake:Hold the button for one second until button turns red to enter awake mode

Ignition: Click button once to ignite the saber

The Functions below will be activated when the blade is ON

Block Mode: Click once to block (imitate the effect when lightsaber takes shooting)

Lockup Mode: Release after one flash(button), then click once to exit

Infinite Color-Changing: Release after after two flashes(button),click to choose color

Fast Color-Changing: Release after after three flashes(button), click to choose color

Turn off the blade: Hold until the blade turns off

The Functions below will be activated when the blade is OFF

Volume Adjustment: Release after one flash to adjust the volume(3 Levels)

Light Effects Changing: Release after two flashes to change light effects(3 Kinds)

Motion Control: Release after three flashes to turn on/off motion control.

<div align="center">3 Kinds: Twist hilt clockwise+anticlockwise/ Stab+pull back/ Swing</div>

<div align="center">(For further help, turn to our Youtube Video or our Online Service)</div>

Flash on Clash: Release after four flashes to turn on/off FOC.

Sound fonts Changing: Hold until heard the sound of the character

(Or use motion:Twist hilt clockwise+anticlockwise when blade pointing up)

Sleep Mode: Hold the button for 10 seconds until button light vanishes

<div align="center">(The lightsaber will automatically turn off after 10 minutes of not-using)</div>

RGB-X 12 Sets of Sound fonts:

The Second	The High Ground
Dark Ages	Rage Knight
The Dark Sword	Princess
The Dark Lord	Scavenger
The Fallen	Emperor
The Count	Serenity

Features:

Strong enough for medium to heavy dueling. Has flash-on-clash effect for realistic saber duels

Ultraloud sound volume and bright LED lights

Removable blade: use the provided tool to loosen the screws in the hilt

This saber has infinitely variable colors to choose from

Removable battery (if you remove the sabers main body)

Sensitive swing and clash sounds like a "real" lightsaber

Can connect 2 sabers directly into one double-blade saber