

# MIKIT

## SAY HELLO TO DK65

User Guide

### Three Ways of Connecting Devices



**Short Press:**  
Hold **FN** first, then the **corresponding key**, and release both keys.

**Long Press:**  
Hold **FN** first, then the **corresponding key**. Hold for 5 seconds until the indicator starts blinking.

### 2.4GHz Mode

1 Toggle the keyboard Mode Switch to the wireless side.



3 Press FN+R to enter 2.4GHz connecting mode.



2 Plug the 2.4GHz receiver into your computer.



4 The indicator turns off when the keyboard is connected successfully.



\*Please find the 2.4GHz receiver inside the package.

### Bluetooth Mode

1 Toggle the keyboard Mode Switch to the wireless side.



3 Select the pairing device [ Mikit DK65 BT ].



2 Short Press FN+Q to make the indicator blink, then Long Press FN+Q to make the indicator flash.



4 The indicator turns off when the keyboard is paired successfully.




\*In order to complete the pairing of the keyboard with a second or third new Bluetooth device, repeat the instructions from Step 2 and replace the "FN+Q" with "FN+W" or "FN+E".

### Wired Mode

1 Toggle the keyboard Mode Switch to the wired side.



2 Plug the USB cable into your device.




\*When being plugged into the computer, the keyboard will start to charge automatically.

\*Caution: The rated power for the charger must not exceed 5V-1A. Connection to a higher power output will damage the keyboard.

### LED Indicator Status Description



The indicator is located between G and H.



#### Bluetooth



Blinking Bluetooth Device #1 Re-Connecting



Flashing Bluetooth Device #1 Pairing On



Blinking Bluetooth Device #2 Re-Connecting



Flashing Bluetooth Device #2 Pairing On



Blinking Bluetooth Device #3 Re-Connecting



Flashing Bluetooth Device #3 Pairing On

#### 2.4GHz



Blinking 2.4GHz Device Re-Connecting



Flashing 2.4GHz Device Pairing On

#### Others



On CapsLock On



Blinking Special Keys Combination Enabled



Blinking Low Battery Level

### Function Keys Combinations



Short Press


Long Press

Press: Mute/Unmute  
Clockwise: Vol+  
Counterclockwise: Vol-

Switch Between Mac/  
Windows Layout

Swap CapsLock  
and Left Ctrl

Backlight On/Off



Up: Brightness +  
Down: Brightness -

WinLock

Battery Level Check  
(The LED Indicator blinks 1, 2, 3, ... 10 times,  
which stands for 10%, 20%, 30%, ... 100% battery level.)

Reset to Default

Previous

Next

Short Press FN+M:  
For Mac, this will enable  
Number Row to work as Multimedia Keys,  
and FN+Number Row to work as Function Keys.  
Short Press again to disable.